

NEW



Perfect for multi-point measurements on high-performance boards 108 Channels of Simultaneous Testing

Delivering triple-digit multichannel measurement


 $\underset{\text{Max.}}{\text{Analog}} \ 108 ch$ 


Analog + Logic 144ch

 $\begin{array}{c} {\rm Signal\ generation\ } \\ {\rm Max.} \end{array} \\ 216ch$ 










## Compact, measures up to 108 channels

### Multi-channel, reduced footprint


The MR8740T achieves testing of up to 108 channels, double that of conventional models, while maintaining the same unit size. Test high-performance ECU boards, with their ever-increasing number of test points, with a single measurement system. Make the most of your limited space for testing systems.



## Isolated design for fault prevention

#### All channels isolated


Isolation of all channels prevents noise from connected devices, with no negative effect due to different ground potential. Eliminate faults and other trouble caused by mistaken wirings and over-voltages / over-currents due to shorted boards.



Between input channels

Between main unit and input channel

\* Only the 8971 and 8973 units are









### MEMORY HICORDER MR8740T

Analog Max. 108ch Test data transfer time

As artificial intelligence advances in automobiles and other advanced industries the need for technology to simultaneously process large volumes of data, as well as safety and security, has arrived. The MR8740T supports your testing needs with simultaneously sampled measurements across multiple channels.







Simultaneous sampling on all channels




\*1: When using 8966 \*2: When using MR8990, U8991

## Transfer time for test data reduced to almost zero

#### Minimize dead time while testing

Previously, calculations and saving/transferring data after measurements were slow processes, and much of the testing time was taken up by dead time while waiting to perform the next test. The MR8740T dramatically reduces the time both for calculations and saving data, almost completely eliminating dead time while performing tests.



### Save recorded data 100 times faster

#### Minimize the time required to save on devices and media

The MR8740T features a brand new interface and faster internal processing, reducing the time required to save measurement data to media. For example, saving that required 10 minutes previously can now be completed in as little as 6 seconds. This saves you the trouble of waiting for data to be saved and improves work efficiency.

Legacy models	USB 2.0	
	036 2.0	1/20 of conventional models
MR8740T	USB 3.0	1/30 of conventional models
	Internal SSD	1/100 of conventional models

#### Save data in real time NEW




#### Save data while measurement is ongoing

The MR8740T saves data in real-time to recording media while measurement is ongoing thanks to a combination of high-speed data transfer performance and high-speed data saving performance. For example, if saving data to the internal SSD, the instrument can save 64 channels of data in real time at a sampling rate of 1 MS/s.



## **Applications**



### **Control simulation**

Generating and measuring signals with a single device eliminates the need to prepare separate measurement and generator devices. Simulated output of various sensor signals and control pulse signals allows you to simulate the test waveforms (DC output, sine wave output) of engine controls for automobiles, high speed trains, and airplanes, and control boards for airbags, brake systems, power steering, and active suspension.







Airbag control test

Brake system control test

Engine control test

## Tests using distortion measurements

Input the analog signal from a strain gauge or extensometer and the analog signal from a stress sensor. Use the scaling function to convert those values to tensile strain, and to convert the stress sensor value to tensile stress. Measure analog and logic at the same time, to simultaneously record a variety of signals with a single test.




Monitor infrastructural deterioration in bridges



Measure stress in moving parts of industrial robots



Multi-point measurement of propellers on wind power generators, etc.





## **ECU Testing**

ECUs are connected to a large number and wide variety of sensors. Add a signal generation unit to simulate these sensors. By measuring the simulation results with a measurement unit at the same time, you can perform all steps from signal generation to measurement with a single MR8740T.

The U8794 also offers resistance output to enable thermistor circuit testing.



## Replace multiple DMMs with a single unit

Replace multiple desktop DMM units with a single MEMORY HiCORDER for measuring multi-channel sensors.

Select from the MR8990 2-channel unit with a wide range, or the U8991 4-channel unit to measure multiple channels.

In addition to reducing the number of units required, system simplification makes maintenance and management easier.

Expandable to a maximum of 108 channels using multiple 4-channel

## 108 Benchtop DMMs

## Replaced with 1 Unit



#### Comparison of DIGITAL VOLTMETER UNIT MR8990 and U8991

External appearance	HOKI ALE PROPERTY OF THE PROPE	* OHONIO CEO		
Model No.	MR8990	U8991		
Measurement functions	No. of channels: 2, for DC voltage measurement	No. of channels: 4, for DC voltage measurement		
Input terminals	Banana input terminal Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	isolated from the unit, the maximum voltage that can		
Measurement range	100, 1000 mV f.s. 10, 100, 1000 V f.s., 5 ranges	1, 10, 100 V f.s., 3 ranges		
Measurement resolution	1/1,000,000 of measurement rang	e (using 24-bit ΔΣ modulation A/D)		
Integration time	20 ms × NPLC (during 50 Hz), 1	6.67 ms × NPLC (during 60 Hz)		
Basic measurement accuracy	±0.01% rdg. ±0.0025% f.s. (at range of 1000 mV f.s.)	±0.02% rdg. ±0.0025% f.s.		
Maximum input voltage	500 V DC (the maximum voltage that can be applied across input pins without damage)	100 V DC (the maximum voltage that can be applied across input pins without damage)		

## Specifications for DC voltage measurements

Measure minute fluctuations in sensor output for automobiles or voltage fluctuations in batteries with high precision and at high resolution. The maximum voltage input is 500 V DC for the MR8990 and 100 V DC for the U8991. Both units also feature high input resistance.



## Real-time Save

## Save data while measurement is ongoing, even with extended recording, high-speed sampling, and numerous channels

The MR8740T offers real-time save functionality that saves data to recording media while measurement is ongoing. Hioki recommends using the instrument's large internal SSD unit when you need to record data for extended periods of time. If you wish to save data after measurement has completed, you can specify a USB drive as the save destination. Additionally, you can use the real-time save function to control how long the instrument can continue measuring without being dependent on the amount of built-in storage memory. Files are saved as 512 MB segments when using the real-time save function.



#### Real-time save capabilities when measuring 108 channels

Save destination	Number of channels	Sampling speed	Supported measurement time	Maximum sampling speed at which real-time saving is supported*1
Internal SSD (480 GB)	108 ch	500 kS/s	About 1 hr.	5 MS/s (12 channels)
USB Drive Z4006 (16 GB)	108 ch	100 kS/s	About 10 min.	1 MS/S (12 channels)*2
PC	108 ch	20 kS/s	Depends on PC capacity	200 kS/s (12 ch)

<sup>\*1:</sup> For 2 channels (no settings for channel 1) \*2 When connected via a USB 3.0 connector only.

#### Maximum sampling speeds at which real-time saving is supported

Save destination	Number of channels used					
Save desimation	Up to 12	12 to 32	33 to 64	65 or more		
Internal SSD	5 MS/s	2 MS/s	1 MS/s	500 kS/s		
USB Drive Z4006	1 MS/s *2	500 kS/s *2	200 kS/s *2	100 kS/s *2		
PC	200 kS/s	100 kS/s	50 kS/s	20 kS/s		

<sup>\*1:</sup> Double channel counts if U8991 is installed. \*2: When connected via a USB 3.0 connector only.


## Amount of time for which data can be saved in real time to internal SSD (reference values)

d: Days h: Hours
min: Minutes s: Seconds

0					
Sampling speed	Up to 12	13 to 32	33 to 64	65 or more	
5 MS/s	50 min	-	-	-	
2 MS/s	2 h 05 min	1 h 02 min 30 s	-	-	
1 MS/s	4 h 10 min	2 h 05 min	1 h 02 min 30 s	-	
500 kS/s	8 h 20 min	4 h 10 min	2 h 05 min	1 h 02 min 30 s	
200 kS/s	20 h 50 min	10 h 25 min	5 h 12 min 30 s	2 h 36 min 15 s	
100 kS/s	1 d 17 h 40 min	20 h 50 min	10 h 25 min	5 h 12 min 30 s	
50 kS/s	3 d 11 h 20 min	1 d 17 h 40 min	20 h 50 min	10 h 25 min	
20 kS/s	8 d 16 h 20 min	4 d 08 h 10 min	2 d 04 h 05 min	1 d 2 h 02 min 30 s	
10 kS/s	17 d 08 h 40 min	8 d 16 h 20 min	4 d 08 h 10 min	2 d 04 h 05 min	
5 kS/s	34 d 17 h 20 min	17 d 08 h 40 min	8 d 16 h 20 min	4 d 08 h 10 min	
2 kS/s	86 d 19 h 20 min	43 d 09 h 40 min	21 d 16 h 50 min	10 d 20 h 25 min	
1 kS/s	173 d 14 h 40 min	86 d 19 h 20 min	43 d 09 h 40 min	21 d 16 h 50 min	
500 S/s	347 d 05 h 20 min	173 d 14 h 40 min	86 d 19 h 20 min	43 d 09 h 40 min	
200 S/s	ł	ì	217 d 00 h 20 min	108 d 12 h 10 min	
100 S/s			ì	217 d 00 h 20 min	


#### Saving data directly to your PC

Transfer measurement data directly to your PC by using the FTP sending function together with the real-time save function. This makes it easier to observe data after the measuring process.



## Long-term measurements for more efficient testing

The real-time save function boasts high-speed sampling and multi-channel measurements. Perform an approximately 1-hour measurement at 5 MS/s in 2 channels or 1 MS/s in 64 channels.



## Complete Product Lineup



Install up to 27 modules

## **Build Your Ideal Inspection System**

Choose from a diverse array of modules to build your perfect test system.

To test a ECU that requires multi-point, high-precision measurements, combine the U8975 and U8991 4-channel units to build a measurement system that delivers a maximum of 108 channels. In addition, create an integrated testing system that can simulate engine behaviors and sensors by utilizing the waveform generators, pulse generators, and VIR generators available on select units.

Use ANALOG UNIT 8966 and DIGITAL VOLTMETER UNIT MR8990 to supplement waveforms of high-speed and high-voltage signals, such as for inverter boards, in the same way as when measuring with a DMM. Combine high-precision units that perform simultaneous sampling for safe and reliable operation in a variety of measurement scenarios.

Unit interchangeability

Use any of the 18 types listed in the unit selection guide below.

The MR8740T is compatible with the same units used for the HIOKI MEMORY HICORDER MR8740, MR8741, MR6000, MR8827, and MR8847A.

### Unit selection guide (18 types available)

	Measured signal	Model No.	Description	No. of channels	Fastest sampling	Bandwidth	A/D resolution	DC accuracy	Max. input voltage	Min. resolution (*1)	Max. sensitivity range	Isolated/ Non- isolated	Notes
	Voltage	8966	ANALOG UNIT	2 ch	20 MS/s	DC to 5 MHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	n/a
	Voltage (multi-channel)	U8975	4ch ANALOG UNIT	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.1% f.s.	200 V DC	0.125 mV	4 V f.s.	Yes	n/a
NEW	Voltage (multi-channel, high resolution)	U8978	4CH ANALOG UNIT	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	40 V DC	3.125 uV	100 mV f.s.	Yes	n/a
	Voltage (high resolution)	8968	HIGH RESOLUTION UNIT	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.3% f.s.	400 V DC	3.125 uV	100 mV f.s.	Yes	with AAF
	Voltage (DC, RMS)	8972	DC/RMS UNIT	2 ch	1 MS/s	DC to 400 kHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	with RMS
	Voltage (high voltage)	U8974	HIGH VOLTAGE UNIT	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.25% f.s.	1000 V DC 700 V AC	0.125 mV	4 V f.s.	Yes	Maximum rated voltage to ground 600 V AC/DC CAT IV
	Voltage (high resolution)	MR8990	DIGITAL VOLTMETER UNIT	2 ch	2 ms	n/a	24 bits	±0.01% rdg. ±0.0025% f.s.	500 V DC	0.1 uV	100 mV f.s.	Yes	Maximum rated voltage to ground 300 V AC/DC CAT II
	Voltage (high resolution)	U8991	DIGITAL VOLTMETER UNIT	4 ch	20 ms	n/a	24 bits	±0.02% rdg. ±0.0025% f.s.	100 V DC	1 uV	1 V f.s.	Yes	Maximum rated voltage to ground 100 V AC/DC
	Current	8971	CURRENT UNIT	2 ch	1 MS/s	DC to 100 kHz	12 bits	±0.65% f.s.	Current sensor only		on current nsor	No	with RMS Max. 4 units
NEW	Current	U8977	3CH CURRENT UNIT	3 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	Current sensor only		on current nsor	No	Max. 3 units
	Temperature	8967	TEMPERATURE UNIT	2 ch	1.2 ms	DC	16 bits	Detailed reference	Thermocouples only	0.01°C	200°C (392°F) f.s.	Yes	n/a
	Strain	U8969	STRAIN UNIT	2 ch	200 kS/s	DC to 20 kHz	16 bits	±0.5% f.s. ±4 με	Strain only	0.016 με	400 μ <b>ε</b> f.s.	Yes	n/a
	Frequency	8970	FREQ UNIT	2 ch	200 kS/s	DC to 100 kHz (*3)	16 bits	n/a	400 V DC	0.002 Hz	Depends on mode	Yes	n/a
NEW	Acceleration	U8979	Charge Unit	2 ch	200 kS/s	DC to 50 kHz (DC) 1 Hz to 50 kHz (AC)	16 bits	±0.5% f.s. (Voltage) ±2.0% f.s. (Acceleration)	40 V DC		nds on ion sensor	Yes	Supports TEDS
	Logic	8973	LOGIC UNIT	4 probes	n/a	n/a	n/a	n/a	n/a	n/a	n/a	No	9320-01,9327, Requires 9320-01, 9327 or MR9321-01

(\*1) Minimum resolution shows the highest sensitivity resolution. (\*2) When using the 9665 (\*3) Minimum pulse width 2 µs

Target	Model No.	Description	Channels	Output	Frequency	Output range
Voltage	MR8791	PULSE GENERATOR UNIT	8 ch	Pulse, pattern	0.1 Hz to 20 kHz (pulse) 10 Hz to 120 kHz (pattern clock)	Logic output (Amplitude: 0 to 5 V), Open collector output
Voltage	MR8790	WAVEFORM GENERATOR UNIT	4 ch	DC, sine wave	DC, 1 Hz to 20 kHz	Output: -10 V to 10 V (Amplitude setting range: 0 to 20 Vpp)
Voltage / Current / Resistance	U8794	VIR GENERATOR UNIT	8 ch	DC voltage, DC current, resistance (simulated output)	n/a	Voltage: -0.1 V to 5.3 V, Current: $\pm 5$ mA, Resistance: 10 $\Omega$ to 1 M $\Omega$

Use communication commands to configure the settings for generator units.





## Unit Advantages

Ideal for simulation testing that involves signal generation and measurement







U8794 for generating voltage, current, and resistance

MR8790 for generating waveform signals


MR8791 for generating pulse signals

### Generate voltage/current signals, pulses and simulated resistance

Use generator units in place of the sensor output for simulation testing or board testing lines using generated signals. Combine a generator unit and measurement unit to perform generation and measurement with a single test system.


#### **VIR GENERATOR UNIT U8794**

Output DC voltage, DC current, and resistance.









Traditional switching resistors are large and take up space.

8 channels with 1 unit

## Easily configure output settings and monitor measured values

You can easily set the constant voltage, constant current, or resistance value to output for each channel. Internal voltage, current, and resistance values can be displayed on the same screen.

### Ideal for testing that requires simulated signals

When used as an ECU testing device, generate simulated signals from various sensors, which is indispensable for testing electronic parts and maintaining equipment.

#### Generator units can simulate a variety of sensor signals

ECU type	Sensor function	Sensor type	Generator unit
	Air flow sensor	Voltage	U8794
	Throttle sensor	Voltage	U8794
	O2 sensor	Voltage	U8794
Engine	Knock sensor	Voltage	MR8790
management	Crank angle sensor	Voltage	MR8791
system	Camshaft sensor	Voltage	MR8791
	Water temperature sensor	Resistance	U8794
	Intake air temperature sensor	Resistance	U8794
Driving management system	Torque sensor G sensor Steering angle sensor Speed sensor	Voltage	MR8790 MR8791 U8794
Safety & comfort management system	Ultrasonic/radar sensor Vibration sensor Refrigerant pressure sensor Humidity sensor	Voltage Resistance	MR8790 MR8791 U8794



#### **Testing electronic parts**

Use the recorder's internal voltage monitor and current monitor to test electronic parts. Or, check resistance values and diode direction characteristics based on the output current and measured voltage.

#### Testing and maintaining equipment

Easily maintain and test equipment involved in voltage and current measurements thanks to high accuracy output.



Simultaneous sampling on all channels across all units




Measure up to 200 V U8975 Measure at 24-bit resolution U8991

Measure with high sensitivity at 100 mV f.s.: U8978

## Ideal for measurements that require simultaneity

All channels are equipped with an A/D converter and measurement timings are synchronized, eliminating sampling time difference between units and channels. This delivers accurate time measurement for cursor readout and time difference measurements.




## Record briefly at high speed, record for a long time at low speed

Use high-speed sampling to capture inverter waveforms, and low-speed sampling to measure RMS values on multiple channels.

#### Maximum recording time to internal memory

	When using a	When using a 4-channel unit		
Sampling rate	2-channel unit	When using U8975, U8978	When using U8991	
Sampling rate	Recording length: 10 M points	Recording length: 5 M points	Recording length: 2 M points	
20 MS/s	0.5 s	0.25 s	0.1 s	
10 MS/s	1 s	0.5 s	0.2 s	
5 MS/s	2 s	1 s	0.4 s	
2 MS/s	5 s	2 s	1 s	
1 MS/s	10 s	5 s	2 s	
500 kS/s	20 s	10 s	4 s	
200 kS/s	50 s	25 s	10 s	
100 kS/s	1 m 40 s	50 s	20 s	
50 kS/s	3 m 20 s	1 m 40 s	40 s	
20 kS/s	8 m 20 s	4 m 10 s	1 m 40 s	
10 kS/s	16 m 40 s	8 m 20 s	3 m 20 s	
5 kS/s	33 m 20 s	16 m 40 s	6 m 40 s	
2 kS/s	1 h 23 m 20 s	41 m 40 s	16 m 40 s	
1 kS/s	2 h 46 m 40 s	1 h 23 m 20 s	33 m 20 s	
500 S/s	5 h 33 m 20 s	2 h 46 m 40 s	1 h 6 m 40 s	
200 S/s	13 h 53 m 20 s	6 h 56 m 40 s	2 h 46 m 40 s	
100 S/s	1 d 3 h 46 m 40 s	13 h 53 m 20 s	5 h 33 m 20 s	
50 S/s	2 d 7 h 33 m 20 s	1 d 3 h 46 m 40 s	11 h 6 m 40 s	
20 S/s	5 d 18 h 53 m 20 s	2 d 21 h 26 m 40 s	1 d 3 h 46 m 40 s	
10 S/s	11 d 13 h 46 m 40 s	5 d 18 h 53 m 20 s	2 d 7 h 33 m 20 s	
5 S/s	23 d 3 h 33 m 20 s	11 d 13 h 46 m 40 s	4 d 15 h 6 m 40 s	
2 S/s	57 d 20 h 53 m 20 s	28 d 22 h 26 m 40 s	11 d 13 h 46 m 40 s	
1 S/s	115 d 17 h 46 m 40 s	57 d 20 h 53 m 20 s	23 d 3 h 33 m 20 s	



## Instantaneous measurement of various inverter waveforms

Simultaneously measure and record multiple phenomena, such as the voltage, current, torque, and rotation signal on the primary and secondary sides of an inverter, from high voltage to minute voltage.

## Highly accurate measurement of RMS values over long periods of time


Use the high-resolution CURRENT UNIT 8971 for highly accurate measurements of RMS values over long periods of time.



## Measurement and Analysis Functions

### Triggers that detect targeted events

Set triggers on any channel to record data whenever an event occurs. This setting can be configured for all channels.




#### Setting multiple triggers for a single channel


Set up to 4 triggers for a single channel.

Sometimes the cause of issues are unclear, preventing you from setting up the proper trigger to capture the necessary waveforms and conduct further analysis. By being able to set glitch, level, windowin, and window-out triggers for the same input waveform, for instance, you can broaden the scope of your investigation and increase your chances of catching the signal anomalies.





Setting Screen with Easy-to-Understand Trigger System Chart



### Warning function using trigger settings

Trigger settings are used to issue a warning if the setting range is exceeded.

For example, during an immunity test, this function can be used to notify the user when the variable limit value of the measured voltage is exceeded. In such cases, a window out trigger is used.


### **Output warning**

- (1) When a waveform exceeds the upper and/or lower limits of the setting range, an event mark is displayed on the screen and an alarm sounds. When the waveform is once again within the upper and/or lower limits of the setting range, the alarm stops and an event mark is displayed on the screen.
- (2) In each case, the time, channel, type of trigger, and voltage measurement value are displayed on the top right side of the screen. \* Effective for sampling at 100 KS/s or less.

#### When unsure about trigger level

### Setting trigger level automatically

Take a preliminary measurement of a specified number of samples before the actual measurement, and use the average of those values to set the trigger level. This function is useful both for the warning function and for normal triggers.



Warning function settings are the same as for triggers, and easy to use.




Warning displayed at the top of the screen when the alarm sounds

### Calculation function with high analytical performance

#### Waveform processing

In addition to calculating numerical values such as average values and RMS values, up to 16 types of simultaneous processing are available by combining calculations in the waveform dimension with differential arithmetic, including the four arithmetic operations, between channels.



Simultaneously make up to 16 waveform calculations by combining the four arithmetic operations and 11 types of calculations

Four arithmetic operations (addition, subtraction, multiplication, and division)	Parallel displacement along time axis (SLI)
Absolute value (ABS)	Differentiation (primary (DIF), secondary (DIF2))
Exponentiation (EXP)	Integration (primary (INT), secondary (INT2))
Common logarithm (LOG)	Trigonometric functions (SIN, COS, TAN)
Square root (SQR), cube root (CBR)	Reverse trigonometric functions (ASIN, ACOS, ATAN, ATAN2)
Moving average (MOV)	MR8990 DIGITAL VOLTMETER UNIT time shift for PLC delay (PLCS)

#### **Numerical calculations**

The MD0740T features equally any properties and calculations including

The MR8740T features several new numerical calculations including overshoot and undershoot calculations.

In addition to analog and logic channels, the recorder performs calculations on waveform processing results. It also features a numerical judgment function.

Simultaneous numerical calculations of up to 16 out of a total of 33 computations

Average value	Duty ratio
RMS value	Pulse count
Peak to peak value	Four arithmetic operations
Maximum value	Time difference
Time to maximum value	Phase difference
Minimum value	High-level
Time to minimum value	Low-level
Period	Median value
Frequency	Amplitude
Rise time	Overshoot
Fall time	Undershoot
Standard deviation	+Width
Area value	-Width
X-Y area value	Burst width
Specified level time	Integration values
Specified time level	XY waveform angle
Pulse width	

## Find a specific waveform within large amounts of measurement data

Set the peak values or trigger conditions you want to search for to have the relevant data retrieved and displayed automatically.

Our new Memory HiCorder HiConcierge function automatically calculates the characteristics of the reference waveform you have set and searches all of the measured data to detect any waveforms with low similarity as anomalous waveforms.

This drastically reduces the amount of time required to search for anomalies by eliminating the need to scroll through measured waveforms and checking them visually.


## Auto search of anomalous waveforms with Concierge

#### **Memory HiCorder Concierge**

A new waveform search function that finds anomalous waveforms in all of the measured data. This function is ideal for situations where it is difficult to set the right triggers before measuring because the nature of potential anomalies cannot be predicted.



Memory HiCorder Concierge Waveform Search Screen



#### Rich set of search methods

#### Peak search

Search for the maximum value, minimum value, local maxima, or local minima in all of the measured data, and mark the search point in the waveform.

#### Trigger search

Set trigger conditions for all of the measured data again to search for points where the conditions are fulfilled, even if no triggers were set during the measuring process.

#### Jump

Jump to an event mark you made while measuring, to the cursor position on the display, or to the location measured at a specified time.







## Smart Links with Monitors and PCs


When building a testing system Monitor MR8740T PC



### Easily check measured waveforms and the settings of communication commands


When building a testing system, use a monitor to easily evaluate captured waveforms in full detail and review the settings for the communication commands sent from a PC. After the system is built, detach the monitor to maximize the use of resources in other applications, while continuing to control the MR8740T with only the PC. Or, if control is not necessary, use only the MR8740T with a monitor to take measurements and observe waveforms in standalone mode.

\* A display with a resolution of 1920 x 1080 or better is recommended.




#### Display system for efficient work

Configure various settings while viewing a variety of information on a single screen. Improve work efficiency by reducing the need to switch or scroll through screens in order to check the settings for each channel.



#### Waveform analysis with 8 cursors

When building a system or analyzing faulty parts, perform a detailed check of waveforms in order to verify proper operation. Use multiple cursors on the MR8740T to smoothly analyze and evaluate actual waveforms.



#### LabView compatibility

NEW

The MR8740T can be controlled with LabVIEW. Search for "MR8740-50" under "Download Software" in the "Support" section of Hioki's website and download the LabVIEW driver



## Control the MR8740T with a single computer

Connect the MR8740T to a computer via LAN in order to control it with communication commands. This allows you to configure, generate, measure, and acquire data with only a single computer. After the testing system is built, remove the monitor for a more compact system.



## Standard recorder when control via PC is not required

If the unit will be used only as a basic recorder and there is no need to use a computer for control, use only the MR8740T together with a monitor to take and record measurements. Display the channel waveforms that are measured with the MR8740T on the monitor in order to quickly analyze and calculate results.

## High-speed communication function

A 1000 BASE-TX LAN terminal is equipped as standard.

## FTP server function


The content of the MR8740T's memory (USB memory and internal SSD) can be copied to the computer.


## FTP transfer function

Measurement data can be transferred directly to the computer.



## Interface





### LEDs indicate unit status

The POWER STANDBY lamp and DIAG lamp indicate the basic status. The CMD ERR lamp lights when an error or warning occurs.

LED name	Color/ flashing	Meaning when on	How to turn off
	Orange	Power standby	Main power switch OFF
POWER STANDBY	Green	Power ON	Activate switch OFF *
STANDBI	Green/ flashing	Power ON (warming up)	Activate switch OFF *
DIAG	See below		-
CMD ERR	Red	Syntax error in command received, or warning occurred	*Goes off with CLS

\* If the POWER STANDBY lamp is steady or flashing green, do not turn the main power switch OFF.

#### **DIAG LED Mode Table**

Display order of priority	Color/ flashing	Status	Supplement
1	Red	Ambient temperature too high (environmental temperature > 35°C/95°F)	
2	Purple	Ambient temperature too low (environmental temperature < 10°C/50°F)	
3	O Yellow	CPU load factor 80% or more	The average load factor is updated every 0.5 seconds.
	Blue	The instrument is in the trigger standby state.	
4	Green	Recording in progress	
	Pink	Recording finished	New command received, switches to normal display.
5	O White	Normal operation in progress (stopped)	

#### Internal battery

The MR8740T is equipped with a battery (sealed lead acid battery) for shutting down the Windows operating system when the power supply is cut off. This allows the unit to be shut down normally even when there is an unexpected power failure or a breaker trips.

Using the battery to shut down normally if there is a power failure



- Breaker OFF - Power outage

(for 150 ms or longer) - Power cord disconnected



\* If the main power switch is switched off while the recorder is in operation, the internal battery will not turn on, preventing the recorder from shutting down normally. Before turning the main power off, be sure to first put the recorder in standby.

Environment	Expected service life
Environmental temperature: 25°C/77°F (when the power is turned off once/day)	2 years
Environmental temperature: 25°C/77°F (when the power is turned off 5 times/year)	4 years

<sup>\*</sup> The internal battery should be replaced regularly, according to the estimated service life indicated in the table above. If the service life is exceeded and a power outage occurs, Windows might not shut down normally, and if so Windows might not start up again normally. Therefore, it is important to replace the battery on a regular basis. At the recommend replacement time, please contact your authorized Hioki distributor or reseller for a replacement battery.

#### Space for units

Max. 27 units can be installed Model 8973 can only be installed in slots 25 to 27

#### 2 USB 2.0 connector x2

#### 3 Activate button

ctivates the unit, or places it in standby

#### 4 POWER lamp Indicates the unit is activated or in standby

5 DIAG light

#### 6 Command error lamp ights when a command error occurs

#### 7 Air vents

For reducing the internal temperature

#### 8 PS2 connector

Not operational with this system

## 9 USB 2.0 connector x2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### 10 COM terminal

Not operational with this system

#### 11 HDMI terminal

For connecting to monitors using an HDMI cable Max. resolution: 3840 x 1260

#### 12 VGA terminal

For connecting to monitors using an RGB cable Max. resolution: 2560 x 1600

#### 13 Display Port terminal

For connecting to monitors using a Display Port cable Max. resolution: 4096 x 2160

#### 14 1000 BASE-T connector

For connecting to the network via a LAN cable

#### 15 USB 3.0 connector x4

For connecting a USB memory stick, USB mouse, or USB keyboard

#### 16 Audio terminals

Not operational with this systen

#### 17 External control terminals

For inputting various external signals to control the device

### 18 Model No., Serial No.

Numbers for identifying the unit

#### 19 Main power switch

For turning the power ON or OFF

\* Place the unit in standby before turning the power OFF

#### 20 Power inlet

onnect the included power cord

#### **External control terminals**


Connect an external device to the external control terminal in order to use that external device to start and stop the measurements made by the unit.


		<b>.</b>
No.	Terminal name	Operation
1	GND	-
2	IN1	Start/stop measurements, save,
3	IN2	forced termination, event input
4	GND	-
5	OUT1	Judgment output, occurrence of errors,
6	OUT2	busy, trigger standby
7	GND	-
- 8	EXT.TRIG	Inputs signal as an external trigger source
9	TRIG.OUT	Outputs a signal when triggering occurs
10	GND	-
11	EXT.SMPL	Inputs external sampling signals

### **Analysis software**

Wave Viewer Wv (Bundled software) Download free updates from the HIOKI website.

The MR8740T ships standard with Wave Viewer Wv, an application for displaying and converting waveforms. The application allows you to review waveforms stored in binary data captured with the MR8740T on a PC and convert files to CSV format so that they can be loaded by Excel.





Sample Wy Screen

Sample Excel Screen

• Wave Viewer (Wv) Brief Specifications

	` '
Operating environment	Windows 10 / 8 / 7 (32 / 64-bit)
Functions	Simple display of waveform files     Convert binary data files to text format, CSV, etc.     Scroll function, enlarge/reduce display, jump to cursor/trigger position, etc.

### WAVE PROCESSOR 9335 (Software sold separately)

Waveform display, calculation, and printing functionality

9335 Brief Specifications

- 0000 DI	Hart Steel of the	
Operating environment	Windows 10 / 8 / 7 (32 / 64-bit)	
Functions	<ul> <li>- Display functions: Waveform display, X-Y display, Cursor fur- - File loading: Readable data formats (MEM, REC, RMS, PC able file size: Maximum file size that can be saved by a give be limited depending on the computer configuration)</li> <li>- Data conversion: Conversion to CSV format, Batch conversi</li> </ul>	OW) / Maximum load- n device (file size may
Printing	- Print function: Printing image file output (expanded META ty	

## Product Specifications

Pania enacification	(Accuracy guaranteed for 1 year Post adjustment appures average of for 1 year)		Output type Open drain output (active less with 5 V values of 10
Basic specificatio Recording method	ns (Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)  Memory Recorder		Output type Open drain output (active low, with 5 V voltage output)  Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level
necording metrica	With ANALOG UNIT 8966 installed: Up to 54 analog channels		Maximum input 50 V DC 50 mA 200 mW
No. of Channels	With LOGIC UNIT 8973 inserted: Up to 48 analog channels + 48 logic channels With ANALOG UNIT U8975 / U8978 / U8991 installed: Up to 108 analog channels With LOGIC UNIT 8973 inserted: Up to 96 analog channels + 48 logic channels * Logic units are limited to slots 25 to 27 only.	Trigger output	Output pulse uicth Level or pulse selection possible Level: Sampling period x data number after trigger
Maximum sampling rate	20 MS/s (with ANALOG UNIT 8966, all channels at the same time) External sampling 10 MS/s		Pulse: 2 ms ±1 ms  Maximum input +10 V DC
Memory capacity	1 G words		Input voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level
	Increase the recording length per channel by limiting the number of modules in use. 27 modules: Using all modules; 16 modules: using modules 1 through 16; 8 modules: using modules 1 through 8, 4 modules: using modules 1 through 4	External sampling	Response 50 ns or more during high periods, 50 ns or more during high periods, 50 ns or more during high periods.
	16 modules 8 modules 4 modules		frequency
Modules		Trigger	Functions External sampling clock input, rising/falling selection pro-
		Trigger type	Digital comparison type
	16MW/ch 32MW/ch 64MW/ch	Trigger conditions	AND or OR condition for trigger sources and interval trigger
Operating	*Measurement will be disabled for modules other than those shown above.		Analog, logic Max. 108 channels
environment	Indoors, Pollution Degree 2, altitude up to 2000 m (6562.20 ft)	Trigger source	Up to 4 analog triggers can be set for each analog channel. Up to 4 logic triggers can be set for each logic probe.
Operating temperature and humidity range	0°C to 40°C (32°F to 104°F), less than 80% RH (no condensation)		The free run function is activated if all trigger sources are turned off.
Storage temperature and humidity range	-10°C to 50°C (14°F to 122°F), 80% RH or less (no condensation)		External trigger  Level trigger Triggering occurs when the set level rises (falls).
Compliance	Safety: EN 61010-1:2010		Voltage drop Triggering occurs when peak voltage drops below the
standards	EMC EN 61326-1: 2013 Class A		trigger (For a 50 Hz / 60 Hz commercial power supply only).  * Not available with MR8990, U8991, or 8970
Dielectric withstand voltage	1620 V AC 1 minute (sensed current: 10 mA) between main unit and power supply		Window trigger  Triggering occurs when leaving (OUT) or entering (IN) the
Power supply	Rated supply voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations for rated supply voltage) Rated power supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V		trigger level upper limit and lower limit setting areas.  Sets the period reference value and cycle range.  Triggering occurs when the rising (falling) reference value.
Maximum rated power consumption	400 VA	Analog triggers	Period trigger period is measured and determined to be outside or with cycle range.  * Not available with MR8990, U8991, or 8970
Clock  Backup battery life	Auto-calendar, leap-year correcting 24-hour clock  Approx. 10 years (at 23°C (73°F)) for clock and settings		Sets the reference value and pulse width (glitch width).
Battery service life	Approx. 2 years (discharged once/day, 23°C (73°F)) *Reference: Approx. 4 years when discharged 5 times/year		Glitch trigger  Triggering occurs if the value is below the set pulse wid rising or falling of the reference value.  *Not available with MR8990 or U8991
Dimensions	426 mm ±2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x 505 ±2 mm (19.88 in ±0.08 in) D (excluding protrusions) 14.0 kg ±0.5 kg (493.8 oz ±17.6 oz) (main unit only)		Specifying events (1 to 4000) Counts the number of times conditions were fulfilled for trigger source. Triggering occurs when the set number
Mass	20.8 kg ±1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)		events times is reached.
Product warranty period  Accessories	1 year     Power cord, Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-R),	Logic trigger	* Not available when the trigger conditions are set to AND  Pattern trigger using 1, 0, or x
	application disk (CD-R), blank panel (blank slot only), rack installation hardware	Forcible trigger	Included (Forcible triggering can be prioritized over all trigger sources.)
Accuracy Accuracy guarantee	Tananantura and humiditurara as 0000 upo (7005 upo (7006 poor) PH and an	Interval trigger	Recording possible at specified measuring intervals (hours, minutes, or see The trigger conditions are fulfilled when the measuring process starts.
conditions	Temperature and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less		Afterwards, the trigger conditions are met at the set measuring intervals.
Time axis accuracy Clock precision	±0.001% ±0.001%	Trigger filter Level setting	OFF, 10, 20, 50, 100, 150, 200, 250, 500, 1000, 2000, 5000, 10,000 san
System (ATX moti	herboard)	resolution	1 LSB (12/16-bit unit)
CPU	Intel Core i5, or a product with similar specifications  DDR4 8 GB	Pre-trigger	0% to 100% (any value set in 1% steps available), displaying the recording time for pre-trigger
Main memory OS	Windows 10	Trigger timing	START
Startup disk	SSD 120 GB		Incompatible with trigger function (Only analog trigger function can be e  If trigger conditions are met : Channel numbers and measured
Compatibility specifications Number of ports	IEEE 802.3 Eihernet 1000BASE-T, 100BASE-TX, 10BASE-T	Warning function	are displayed/saved, an event m displayed, and an alarm sounds. If trigger conditions are no longer met: Channel numbers and measured are displayed/saved, an event m
Functions	DHCP, DNS, FTP, HTTP		displayed, and the alarm stops.
Connector	RJ-45	Auto trigger lovel	ON/OFF (trigger function, warning function) Several data samples are taken, and the average value is set as the crite
USB interface Compatibility		Auto trigger level	the window out trigger.  Number of samples: Select from 100, 200, 300, 400, and 500
specifications	USB 3.0 compliant x 4, USB 2.0 compliant x 4	Waveform screen	
Connected devices Connector	Keyboard, mouse, USB memory stick Series A receptacle		Waveform display in 1 screen, 2 screens, 4 screens, 8 screens, 16 screens
Monitor output	VGA Resolution: 2560 x 1600 dots (Max.)	Display format	display in chronological order "Displays up to 64 channels per sheet. "Multiple sheets can be set for the same channel.
Output type	HDMI Resolution: 3840 x 2160 dots (Max.) Display Port Resolution: 4096 x 2304 dots (Max.)	Sheet function	Max. 16 sheets *The display format can be selected for each sheet.
External I/O termi	Recommended resolution: 1920 x 1080 dots or better	Zoom display	ON / OFF Waveforms are displayed in chronological order in the top part of the war
Terminal block	Push-button type	Full coroon diaplay	screen, whereas the zoomed waveforms are displayed in the bottom part Displays waveforms over the entire waveform screen.
	Maximum input voltage +10 V DC	Full screen display	Wayeform
	Input voltage 2.5 V to 10 V for high level, 0 V to 0.8 V for low level		color Fixed colors (32 colors)
External input	Response 50 ms or more during high periods, 50 ms or more during low pulse width periods		Interpolation Linear  Variable About ON
External input	Pulse interval 200 ms or greater		display
	Number of 2	Waveform display	Vernier Adjustable input waveform (Adjustment range: 50% to 200% of the input)
	terminals		Grid OFF / ON
	Functions START, STOP, START/STOP, SAVE, ABORT, event		Lauria disalar.
	terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level		Logic display width Wide, Standard, Narrow
Futoros!	Terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output)		width wide, Standard, Narrow  Waveform Displays waveforms upside down.
External output	terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage 50 V DC, 50 mA, 200 mW Number of 2	Enlarge / Reduce	width Wide, Staridard, Narrow
External output	terminals  Functions START, STOP, START/STOP, SAVE, ABORT, event  Output type Open drain output (active low, with 5 V voltage output)  Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level  Maximum input voltage 50 V DC, 50 mA, 200 mW  Number of terminals  2  Eurotions Judgment (PASS), judgment (FAIL), occurrence of errors,	Enlarge / Reduce Waveform scrolling	width wide, Standard, Narrow  Waveform Displays waveforms upside down. inversion * Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.
External output	terminals  Functions  START, STOP, START/STOP, SAVE, ABORT, event  Output type  Open drain output (active low, with 5 V voltage output)  Output voltage  4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level  Maximum input  50 V DC, 50 mA, 200 mW  Number of terminals  Functions  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby	Waveform scrolling	width wide, Standard, Narrow  Waveform Displays waveforms upside down. inversion * Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.
External output	terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage Number of terminals Functions Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  ### Additional Processing Start (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  #### Additional Processing Start (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  ###################################	Waveform scrolling Roll display	width Wide, Standard, Narrow  Waveform Displays waveforms upside down. inversion * Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.  Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected.  The roll cannot be displayed when the overlay function is turned on.
External output	terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage Number of terminals Functions Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  Maximum input	Waveform scrolling	width Wide, Standard, Narrow Waveform Displays waveforms upside down. inversion *Not available with 8967, 8970, or 8973 Zoom ratio can be adjusted as necessary. Scroll left or right by with mouse clicks and scroll back while measuring. Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected.
External output	Terminals  Functions  START, STOP, START/STOP, SAVE, ABORT, event  Output type  Open drain output (active low, with 5 V voltage output)  Output voltage  4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level  Maximum input voltage  Number of terminals  Functions  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Additional output voltage**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Additional output voltage**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  **Inctions**  **Inctions**  Judgment (PASS), judg	Waveform scrolling Roll display Level monitor	width Wide, Starldard, Narrow Waveform Displays waveforms upside down. inversion *Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.  Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected. The roll cannot be displayed when the overlay function is turned on.  Numerical display  Up to 8 cursors can be displayed.
·	terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input voltage Number of terminals Functions Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby Maximum input voltage External trigger filter  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods Trigger filter ON : 2.5 ms or more during high periods,	Waveform scrolling Roll display Level monitor	width Wide, Standard, Narrow Waveform Displays waveforms upside down. inversion *Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.  Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected. The roll cannot be displayed when the overlay function is turned on.  Numerical display
·	terminals Functions START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level Maximum input 50 V DC, 50 mA, 200 mW  Number of terminals Functions Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  Maximum input voltage to V DC  External trigger filter External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods	Waveform scrolling Roll display Level monitor	width Wide, Starldard, Narrow Waveform Displays waveforms upside down. inversion * Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.  Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected. The roll cannot be displayed when the overlay function is turned on.  Numerical display  Up to 8 cursors can be displayed.  Tracing cursor ** Displays potential, time from trigger, time difference be cursors, and potential difference.  Horizontal Up to 8 cursors can be displayed.
·	Terminals  Functions  START, STOP, START/STOP, SAVE, ABORT, event  Output type  Open drain output (active low, with 5 V voltage output)  Output voltage  Maximum input  50 V DC, 50 mA, 200 mW  Number of terminals  Functions  Maximum input  10 V DC  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  Maximum input  +10 V DC  External trigger filter  Response pulse width  Trigger filter ON : 2.5 ms or more during high periods, 2.5 ms or more during low periods  Rising/falling selection possible  Rising: Triggering occurs when the voltage rises from low	Waveform scrolling Roll display Level monitor function	width Wide, Standard, Narrow Waveform Displays waveforms upside down. inversion *Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.  Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected. The roll cannot be displayed when the overlay function is turned on.  Numerical display  Up to 8 cursors can be displayed.  Tracing cursor  "Displays potential, time from trigger, time difference be cursors, and potential difference.
External output  External trigger	Functions  START, STOP, START/STOP, SAVE, ABORT, event Output type Open drain output (active low, with 5 V voltage output) Output voltage Maximum input 50 V DC, 50 mA, 200 mW  Voltage Number of terminals Functions  Maximum input 410 V DC  Lexternal trigger filter  Response pulse width  Trigger filter ON : 2.5 ms or more during high periods, 2.5 ms or more during low periods Rising/falling selection possible Rising: Triggering occurs when the voltage falls from high Functions  START, STOP, START/STOP, SAVE, ABORT, event 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 4.0 V DC  START, STOP, START/STOP, SAVE, ABORT, event 4.0 V to 5.0 V for high 15 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 4.0 V to 5.0 V for high 15 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 5.0 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 5.0 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 5.0 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 5.0 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 5.0 V of No V on No V to 0.5 V to 0.5 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 5.0 V voltage output)  START, STOP, START/STOP, SAVE, ABORT, event 5.0 V voltage output)  START, STOP, START/STOP, STOP, STORT, event 5.0 V on No V to 0.5 V to 0.5 V to 10 V.  START, STOP, START, STOP, STORT, event 5.0 V on No V to 0.5 V to 0.5 V to 10 V.  START, STOP, START, STOP, STORT, event 5.0 V on No V to 0.5 V to 10 V.  START, STOP, START, STOP, STORT, event 5.0 V on No V to 0.5 V to 10 V.  START, STOP, START, STOP, STORT, event 5.0 V on No V to 0.5 V to 10 V.  START, STOP, START, STOP, STORT, event 5.0 V on No V to 0.5 V to 0.5 V to 10 V.  START, STOP, STORT, event 5.0 V on No V to 0.5 V to 10 V.  START, STOP, STORT, event 5.0 V on No V to 0.5 V to 10 V.  START, STOP, STORT, event 5.0 V on No V to 0.5 V to 10 V.  START, STOP, STORT, event 5.0 V on No V to 0.5 V to 10 V.  START, STORT	Waveform scrolling Roll display Level monitor function	width Wide, Stardard, Narrow Waveform Displays waveforms upside down. inversion *Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.  Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected. The roll cannot be displayed when the overlay function is turned on.  Numerical display  Up to 8 cursors can be displayed.  Tracing cursor *Displays potential, time from trigger, time difference be cursors, and potential difference.  Horizontal Up to 8 cursors can be displayed.  Gauge Up to 8 gauges can be displayed.  Jump Click with the mouse to jump to the specified location.
	Terminals  Functions  START, STOP, START/STOP, SAVE, ABORT, event  Output type  Open drain output (active low, with 5 V voltage output)  Output voltage  4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level  Maximum input  50 V DC, 50 mA, 200 mW  Number of terminals  Functions  Judgment (PASS), judgment (FAIL), occurrence of errors, busy, trigger standby  Maximum input  +10 V DC  External trigger filter  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods  Trigger filter ON: 2.5 ms or more during low periods  Rising/falling selection possible  Rising: Triggering occurs when the voltage rises from low  (0 V to 0.8 V) to high (2.5 V to 10 V).	Waveform scrolling Roll display Level monitor function	width Wide, Starldard, Narrow Waveform Displays waveforms upside down. inversion *Not available with 8967, 8970, or 8973  Zoom ratio can be adjusted as necessary.  Scroll left or right by with mouse clicks and scroll back while measuring.  Always displays the latest data by following the measuring process. The drawing start position (left or right edge) can be selected. The roll cannot be displayed when the overlay function is turned on.  Numerical display  Up to 8 cursors can be displayed.  Tracing cursor "Displays potential, time from trigger, time difference be cursors, and potential difference.  Horizontal Up to 8 cursors can be displayed.  Cursor "Displays potential and potential difference.  Gauge Up to 8 gauges can be displayed.

	Output type Output voltage	4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level			
T	Maximum input	50 V DC, 50 mA, 200 mW			
Trigger output	voltage	Level or pulse selection possible			
	Output pulse width	Level: Sampling period x data number after trigger Pulse: 2 ms ±1 ms			
	Maximum input voltage	+10 V DC			
	Input voltage	2.5 V to 10 V for high level, 0 V to 0.8 V for low level			
External sampling	Response pulse width	50 ns or more during high periods, 50 ns or more during low periods			
	Maximum input	10 MHz			
	frequency Functions	External sampling clock input, rising/falling selection possible			
Trigger	T diletions	External sampling clock input, haring/lailing selection possible			
Trigger type	Digital comparis	on type			
Trigger conditions		dition for trigger sources and interval trigger			
	Analog, logic Max. 108 channels				
Trigger source	Up to 4 analog triggers can be set for each analog channel. Up to 4 logic triggers can be set for each logic probe.				
	The free run fund	ction is activated if all trigger sources are turned off.			
	External trigger Level trigger	Triggering occurs when the set level rises (falls).			
	Voltage drop	Triggering occurs when peak voltage drops below the set level			
	trigger	(For a 50 Hz / 60 Hz commercial power supply only).  * Not available with MR8990, U8991, or 8970			
	Window trigger	Triggering occurs when leaving (OUT) or entering (IN) the			
		trigger level upper limit and lower limit setting areas.  Sets the period reference value and cycle range.			
	Davis d trianger	Triggering occurs when the rising (falling) reference value period is measured and determined to be outside or within the			
Analog triggers	Period trigger	cycle range.			
3 330.0		* Not available with MR8990, U8991, or 8970  Sets the reference value and pulse width (glitch width).			
	Glitch trigger	Triggering occurs if the value is below the set pulse width from			
		rising or falling of the reference value. * Not available with MR8990 or U8991			
		Specifying events (1 to 4000)			
	Specifying events	Counts the number of times conditions were fulfilled for each trigger source. Triggering occurs when the set number of			
	events	times is reached. * Not available when the trigger conditions are set to AND			
Logic trigger	Pattern trigger u				
Forcible trigger		le triggering can be prioritized over all trigger sources.)			
Interval trigger		ible at specified measuring intervals (hours, minutes, or seconds) ditions are fulfilled when the measuring process starts.			
		trigger conditions are met at the set measuring intervals.			
Trigger filter Level setting		100, 150, 200, 250, 500, 1000, 2000, 5000, 10,000 samples			
resolution	1 LSB (12/16-bit				
Pre-trigger		value set in 1% steps available), ecording time for pre-trigger			
Trigger timing	START				
Warning function	If trigger condition	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met: Channel numbers and measured values			
	lgg	are displayed/saved, an event mark is			
	ON/OFF (trigger	displayed, and the alarm stops.  function, warning function)			
Auto trigger level	Several data sar the window out t	nples are taken, and the average value is set as the criteria for			
		oles: Select from 100, 200, 300, 400, and 500			
Waveform screen	1				
Display format	Waveform				
	display in chronological order	1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel.			
Sheet function	chronological order Max. 16 sheets	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.			
Sheet function	chronological order  Max. 16 sheets  *The display form	* Displays up to 64 channels per sheet.			
Sheet function Zoom display	chronological order  Max. 16 sheets *The display form  ON / OFF  Waveforms are of	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform			
Zoom display	chronological order  Max. 16 sheets *The display form  ON / OFF  Waveforms are of screen, whereas	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.			
	chronological order  Max. 16 sheets	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part.			
Zoom display	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are c screen, whereas Displays wavefor Waveform color	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)			
Zoom display	chronological order Max. 16 sheets The display form ON / OFF Waveforms are c screen, whereas Displays wavefor Waveform color Interpolation Variable	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear			
Zoom display Full screen display	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are o screen, whereas Displays waveform color Interpolation Variable display	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON			
Zoom display	chronological order Max. 16 sheets "The display form ON / OFF Waveforms are core, whereas Displays waveform color Interpolation Variable display Vernier	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)			
Zoom display Full screen display	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are o screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform			
Zoom display Full screen display	chronological order Max. 16 sheets "The display form ON / OFF Waveforms are core, whereas Displays waveform color Interpolation Variable display Vernier	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)			
Zoom display Full screen display	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are o screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display Waveform	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.			
Zoom display Full screen display	chronological order Max. 16 sheets The display form ON / OFF Waveforms are of screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow			
Zoom display  Full screen display  Waveform display	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are a screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can b Scroll left or righ	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  De adjusted as necessary.  It by with mouse clicks and scroll back while measuring.			
Zoom display  Full screen display  Waveform display	chronological order Max. 16 sheets "The display form ON / OFF Waveforms are a screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can t Scroll left or righ Always displays	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveforms is the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform  (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  De adjusted as necessary.			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are a screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can b Scroll left or righ Always displays The drawing sta The roll cannot b	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.  *Not available with 8967, 8970, or 8973  be adjusted as necessary.  to by with mouse clicks and scroll back while measuring.  the latest data by following the measuring process.			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce  Waveform scrolling	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are a screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can b Scroll left or righ Always displays The drawing sta	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  This over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  De adjusted as necessary.  tby with mouse clicks and scroll back while measuring.  the latest data by following the measuring process.  rt position (left or right edge) can be selected.			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor	chronological order Max. 16 sheets "The display form ON / OFF Waveforms are a screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can t Scroll left or righ Always displays The drawing sta The roll cannot to Numerical	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  This over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  De adjusted as necessary.  tby with mouse clicks and scroll back while measuring.  the latest data by following the measuring process.  rt position (left or right edge) can be selected.			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor	chronological order  Max. 16 sheets  'The display form ON / OFF Waveforms are of screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can be Scroll left or righ Always displays The drawing sta The roll cannot be Numerical display Tracing cursor Horizontal	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  Ima over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Up with mouse clicks and scroll back while measuring.  The latest data by following the measuring process.  Art position (left or right edge) can be selected.  De displayed when the overlay function is turned on.  Up to 8 cursors can be displayed.  *Displays potential, time from trigger, time difference between cursors, and potential difference.  Up to 8 cursors can be displayed.			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor function	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are a screen, whereas Displays waveform Color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can b Scroll left or righ Always displays The drawing sta The roll cannot b Numerical display Tracing cursor Horizontal cursor	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  Imas over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.  *Not available with 8967, 8970, or 8973  a edjusted as necessary.  It by with mouse clicks and scroll back while measuring.  the latest data by following the measuring process.  It position (left or right edge) can be selected.  be displayed when the overlay function is turned on.  Up to 8 cursors can be displayed.  *Displays potential, time from trigger, time difference between cursors, and potential difference.  Up to 8 cursors can be displayed.  *Displays potential and potential difference.  Up to 8 potential difference.			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor function	chronological order  Max. 16 sheets  'The display form ON / OFF Waveforms are of screen, whereas Displays waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can be Scroll left or righ Always displays The drawing sta The roll cannot be Numerical display Tracing cursor Horizontal	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  Ima over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  Displays waveforms upside down.  * Up with mouse clicks and scroll back while measuring.  The latest data by following the measuring process.  Art position (left or right edge) can be selected.  De displayed when the overlay function is turned on.  Up to 8 cursors can be displayed.  *Displays potential, time from trigger, time difference between cursors, and potential difference.  Up to 8 cursors can be displayed.			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor function	chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are of screen, whereas Displays waveform Color Interpolation Variable display Vernier Grid Logic display width Waveform Inversion Zoom ratio can be Scroll left or right Always displays The drawing sta The roll cannot be Numerical display Tracing cursor Horizontal cursor Gauge Jump Input available of	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  Ima over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  De adjusted as necessary.  It by with mouse clicks and scroll back while measuring.  the latest data by following the measuring process.  rt position (left or right edge) can be selected.  De displayed when the overlay function is turned on.  Up to 8 cursors can be displayed.  "Displays potential, time from trigger, time difference between cursors, and potential difference.  Up to 8 gauges can be displayed.  "Displays potential and potential difference.  Up to 8 gauges can be displayed.  "Displays potential and potential difference.  Up to 8 gauges can be displayed.  "Displays potential and potential difference.  Up to 8 gauges can be displayed.  "Displays potential and potential difference.  Up to 8 gauges can be displayed.  "Displays measuring process (up to 10,000 marks)			
Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor function  Cursor	chronological order  Max. 16 sheets  'The display form ON / OFF Waveforms are of screen, whereas Displays waveform Color Interpolation Variable display Vernier  Grid Logic display width Waveform inversion Zoom ratio can be Scroll left or righ Always displays The drawing sta The roll cannot be Numerical display Tracing cursor Horizontal cursor Gauge Jump Input available of Click the start io	* Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.  In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.  *Not available with 8967, 8970, or 8973  be adjusted as necessary.  to by with mouse clicks and scroll back while measuring.  the latest data by following the measuring process.  It position (left or right edge) can be selected.  be displayed when the overlay function is turned on.  Up to 8 cursors can be displayed.  *Displays potential, time from trigger, time difference between cursors, and potential difference.  Up to 8 cursors can be displayed.  *Displays potential and potential difference.  Up to 8 gauges can be displayed.  *Displays potential and potential difference.  Up to 8 gauges can be displayed.  *Click with the mouse to jump to the specified location.			



0.411				
Setting screen		20 M.	10 M, 5 M, 2 M, 1 M, 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5	
	Real-time sampling	k, 2 k, Extern	1 k, 500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s] al sampling: Max. 10 MHz depending on external sampling	
Sampling speed	With real-time saving enabled ". Values in parentheses indicate number of channels	Maxim [Using 5 MS, 64 ch [Using 1 MS, (25 to [Using 200 k (25 to *USB)	al input signal um configurable sampling speed internal SSD as save destination] is (up to 12 channels), 2 MS/s (13 to 32 channels), 1 MS/s (33 to annels), 500 kS/s (65 or more channels) USB Drive Z4006 as save destination] is (up to 12 channels), 500 kS/s (13 to 12 channels), 100 kS/s (65 or more channels), 200 kS/s (18 de Channels), 100 kS/s (65 or more channels), 200 kS/s (18 to 24 channels), 50 kS/s (18 to 24 chann	
Maximum recording length	Real-time sampling	(Fixed When u 10 M When u MR85 When u MR85 (User-s When u MR85 Whe	le all channel counts if the U8991 is installed.  recording lengths]  using 27 modules: 2 M (with U8991), 5 M (with U8975, MR8990),  (54 channels) [points]  using 18 modules: 5 M (with U8991), 10 M (with U8975,  1890), 20 M (32 channels) [points]  using 8 modules: 10 M (with U8991), 20 M (with U8975,  190), 50 M (16 channels) [points]  using 4 modules: 20 M (with U8991), 50 M (with U8975,  190), 100 M (8 channels) [points]  using 27 modules: 4194,300 (with U8991), 8388600 (with U8975,  190), 17077200 (54 channels) [points]  using 16 modules: 4394,400 (with U8991), 16777200 (with U8975,  190), 3554,400 (32 channels) [points]  using 8 modules: 16777200 (with U8991), 33554400 (with U8975,  190), 67108800 (16 channels) [points]  using 4 modules: 33564400 (with U8991), 67108800 (with U8975,  190), 67108800 (16 channels) [points]  using 190), 134217600 (8 channels) [points]  using 190), 134217600 (8 channels) [points]	
	With real-time saving enabled	and nu	nined by space available on save destination, file system, umber of measurement channels	
Repeat measurement			eat measurement, user-specified count acified count settings are not available when real-time saving	
Scaling	Conversion ratio * Model: Select a	model t	fset, 2-point input, Model, Output rate, dB, Rating o configure the scaling settings automatically. d automatic scaling are available when a current unit is used.	
Comments	Title comments,	channe rs and		
Help	Displays the inst		manual	
Saving	SSD	Intern	al SSD (480 GB)	
	USB MEMORY		6 (16 GB)	
Save destination	Sending to FTP PC with a LAN connection			
File format	email		file to specified email address	
Filename	FAT, FAT32, NTF Alphanumeric a			
Processing identical filenames	Adding a serial r the file when trans		at the beginning before saving (Date and time added after by FTP)	
Auto saving	* Automatically sa measuring proc * Settings files are	ON/OFF  * Automatically saves the data obtained for the recording length at the end of a measuring process.  * Settings files are not supported.  * If a memory division is set, it is possible for measurement of the next block to start		
Deleting and saving	Deletes the files	with the n the sp saving	e oldest creation dates and saves data when there is no pecified media at the save destination.	
	Settings data Measurement	SET	of annual (MEN) and format (OO)	
	data Index		r format (.MEM), text format (.CSV) ad saving (.IDX)	
Types of saved data	Displayed			
	Images BMP, PNG, JPG Numerical CSV			
	1 2 2			
	calculation results Startup		TUP.SET	
Saving channels	Startup Select a channe	STAR	Il the channels available or from the displayed channels	
	Startup Select a channe when saving me Measurement da	STAR I from a asurem ata (text	Il the channels available or from the displayed channels nent data. format) is culled according to the specified culling value	
Saving channels  Culled data saving	Startup Select a channe when saving me Measurement da (from 2 to 1000) b	STAR I from a assurem ata (text perfore s	Ill the channels available or from the displayed channels nent data. format) is culled according to the specified culling value aving.	
Culled data saving	Startup Select a channe when saving me Measurement da	STAR I from a assurem ata (text perfore s	Il the channels available or from the displayed channels nent data. format) is culled according to the specified culling value	
	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format Text format	STAR Il from a easurem ata (text pefore s	Ill the channels available or from the displayed channels sent data. format) is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data	
Culled data saving	Startup Select a channe when saving me Measurement da (from 2 to 1000) b Types of saved Binary format	STAR Il from a easurem ata (text pefore s	Ill the channels available or from the displayed channels sent data. format) is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data	
Culled data saving	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results New files or exis * Enabled when n * Select whether t	STAR all from a sasurem ata (text perfore selection) and the selection at	Ill the channels available or from the displayed channels sent data. format pis culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number	
Culled data saving File division	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results  New files or exis * Enabled when n	STAR  I from a assurem ata (text before s I data  culation  ting file numerica o create  Use th a filent	Ill the channels available or from the displayed channels sent data.  format jis culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  s  al calculation results are saved. a new file or add data to an existing file when starting to  the SAVE operation to save data to a save destination, under  ame, and with saving settings that have been pre-set.	
Culled data saving  File division  Specifying files  SAVE operation	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results New files or exis * Enabled when n * Select whether t measure.	STAR of Irom a seasurement of the seasurement of th	Ill the channels available or from the displayed channels sent data. format) is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 16,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  S al calculation results are saved. a new file or add data to an existing file when starting to be EAVE operation to save data to a save destination, under	
Culled data saving File division Specifying files	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results New files or exis * Enabled when n * Select whether t measure.  Instant saving  Saving range	STAR Il from a assurem ata (text lext lext lext lext lext lext lext	Ill the channels available or from the displayed channels sent data. format is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  Selection of the calculation number of the calculation of the calculation file when starting to the same and with saving settings that have been pre-set. The full range or a specific segment. Ided only when data is saved with the SAVE operation.	
Culled data saving  File division  Specifying files  SAVE operation	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format Numerical calc results New files or exis 'E-nabled when n 'Select whether t measure. Instant saving Saving range  SSD USB MEMORY	STAR If from a seasurem that (text before s data ) data data	Ill the channels available or from the displayed channels sent data. format is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  I calculation results are saved. I a new file or add data to an existing file when starting to the SAVE operation to save data to a save destination, under ame, and with saving settings that have been pre-set. The full range or a specific segment. Isled only when data is saved with the SAVE operation.	
Culled data saving File division Specifying files SAVE operation Loading data	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results New files or exis * Enabled when n * Select whether t measure.  Instant saving  SSD  USB MEMORY STICK	STAR If from a saurem that (text seefore s data ) and the seefore s data	Ill the channels available or from the displayed channels sent data. format is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  Selection of the calculation number of the calculation of the calculation file when starting to the same and with saving settings that have been pre-set. The full range or a specific segment. Ided only when data is saved with the SAVE operation.	
Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format Text format Numerical calc results New files or exis Enabled when n Select whether t measure. Instant saving Saving range  SSD USB MEMORY STICK Settings data Measurement	STAR: If from a lasurem at a (lext file file file file file file file file	Ill the channels available or from the displayed channels sent data. format is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  I calculation results are saved. I a new file or add data to an existing file when starting to the SAVE operation to save data to a save destination, under arme, and with saving settings that have been pre-set. It the full range or a specific segment. Saved with the SAVE operation.  I SSD (480 GB)  S (16 GB)	
Culled data saving File division Specifying files SAVE operation Loading data	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results  New files or exis * Enabled when n * Select whether t measure.  Instant saving  Saving range  SSD  USB MEMORY STICK Settings data	STAR II from a nasurem as a lore to the form a surem as a lore to the form a surem as a lore to the form a lore to the form a filen. Select a filen. Z4006 SET Binary	Ill the channels available or from the displayed channels sent data. format is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  I calculation results are saved. I a new file or add data to an existing file when starting to the SAVE operation to save data to a save destination, under ame, and with saving settings that have been pre-set. The full range or a specific segment. Isled only when data is saved with the SAVE operation.	
Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded data	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format Text format Numerical calc results New files or exis * Enabled when n * Select whether t measure.  Instant saving Saving range  SSD USB MEMORY STICK Settings data Measurement data Index Startup	STAR Il from a assurem a susurem de la fina data (text selfore	Ill the channels available or from the displayed channels tent data. format jis culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  In a calculation results are saved.  In a new file or add data to an existing file when starting to the save of the save of the save destination, under arme, and with saving settings that have been pre-set. The full range or a specific segment. Saved only when data is saved with the SAVE operation.  In SSD (480 GB)  If format (MEM), text format (CSV)	
Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded data  Numerical calculations	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results  New files or exis * Enabled when n * Select whether t measure.  Instant saving  Saving range  SSD  USB MEMORY STICK Settings data Measurement data Index Startup	STAR Il from a assurem la reconstruction de la reco	Ill the channels available or from the displayed channels sent data.  format) is culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 16,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  s al calculation results are saved. a new file or add data to an existing file when starting to be SAVE operation to save data to a save destination, under ame, and with saving settings that have been pre-set.  It the full range or a specific segment.  It the full range or a syecific segment.  It the full (BB)  (16 GB)	
Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded data  Numerical calcula  Maximum number of calculations	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results  New files or exis * Enabled when n * Select whether t measure.  Instant saving  Saving range  SSD  USB MEMORY STICK Settings data Measurement data Index Startup  tions  108 items x Mea	STAR II from a assurem assurem to the state (lext and selections) and selections as the state (lext and selections) and selections are stated as the selection are s	Ill the channels available or from the displayed channels sent data.  format jis culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  standard and the calculation number of the calculation results are saved.  a new file or add data to an existing file when starting to be SAVE operation to save data to a save destination, under ame, and with saving settings that have been pre-set.  the full range or a specific segment.  seled only when data is saved with the SAVE operation.  all SSD (480 GB)  6 (16 GB)  or format (MEM), text format (.CSV)  and saving (.IDX)  TUP.SET	
Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded data  Numerical calcula Maximum number of	Startup Select a channe when saving me Measurement di (from 2 to 1000) b Types of saved Binary format  Text format  Numerical calc results  New files or exis E-nabled when n Select whether t measure.  Instant saving  Saving range  SSD  USB MEMORY STICK Settings data Measurement data Index Startup titions  108 items x Mea Full range or Spe	STAR Il from a assurem la filono della filon	Ill the channels available or from the displayed channels sent data.  format jis culled according to the specified culling value aving.  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  stal calculation results are saved.  a new file or add data to an existing file when starting to be EAVE operation to save data to a save destination, under ame, and with saving settings that have been pre-set.  the full range or a specific segment.  seled only when data is saved with the SAVE operation.  all SSD (480 GB)  6 (16 GB)  or format (MEM), text format (.CSV)  and saving (.IDX)  TUP.SET	

Calculation items	average value, F frequency (*), pe value, time differ minimum value, arithmetic opera	Jue, maximum value, minimum value, high level, low level, IMS value, standard deviation, rise time (*), fall time (*), riod (*), pulse duty ratio (*), pulse count, area value, X-Y area ence (*), phase difference (*), time to maximum value, time to specified level time, specified time level, pulse width (*), four tions, median value, amplitude, integration value burst width (*),
		gle, overshoot, undershoot, + Width (*), - Width (*) statistical function
	Targeted	Analog channels, logic channels, waveform processing
	waveforms Judgment	channels
Numerical judgment	settings	ON/OFF
	Stop	PASS, FAIL, PASS&FAIL
W .	conditions	17.00,17.12,17.00d17.1E
Waveform proces	sing	
Maximum number of calculations	16 formulas	
Calculation range	Full range or Spi	ecified segments
Maximum recording	2,000,000 point	
length		
Standard operator	+,-,×,÷	square root, logarithm, exponentiation, SIN, ASIN, COS, ACOS,
Calculation items	TAN, ATAN, diffe	erentiation, secondary differentiation, integration, secondary
	_	ing average, slide, PLCS
Memory segment		
Max. divisions	1024 blocks	data that is accord in divided manner (block
Block search Past waveform		data that is saved in divided memory block.  measured waveform data into the desired block area and
comparison		creen to the current waveform.
Bulk save	Saves a huge ra	nge of data in all blocks
Display	Specify a block	to display.
Waveform search		
	Trigger	Level, window-in, window-out  If a logic channel is chosen as the target channel, searches can
		be made using logic triggers.
Search methods	Peak	Maximum, minimum, local maximum, local minimum
Search methods	Concierge	Histogram or standard deviation *Choose to compare to corresponding fundamental waves or
		immediately prior waveforms.
	Jump	Event mark, cursor, time (specified as absolute time, relative time, or number of points), trigger point, search mark
	Full range	All data stored in internal memory
Search range	Specified	Choose a range specified by A/B or C/D.
Canab asset	interval	
Search count	Up to 10,000 poir	cified number of search targets remain in the search range after
Continuous search	performing a sea	rch, you can continue to search waveform data after the last search
Display method	point.	
Other	Opecity a search	n location to display the data.
	Available	
Auto range	The optimal sam	upling rate and measurement range for the input waveform are
	The optimal sam automatically se	
	The optimal sam automatically se * Not available with OFF, Alarm only	t. h external sampling Alarm and operation
Auto range	The optimal sam automatically se * Not available wi OFF, Alarm only Sending e-mails	t. h external sampling Alarm and operation
Auto range	The optimal sam automatically se * Not available with OFF, Alarm only	t. h external sampling Alarm and operation
Auto range Beep sound	The optimal sam automatically se * Not available wi OFF, Alarm only Sending e-mails Sending timing	th external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a
Auto range  Beep sound  Sending e-mails	The optimal sam automatically se * Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data	t. h external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.
Auto range  Beep sound  Sending e-mails  Initialization	The optimal sam automatically se  * Not available wi  OFF, Alarm only  Sending e-mails  Sending timing  Sent data  Waveform data i	t. hexternal sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization
Auto range  Beep sound  Sending e-mails  Initialization Self-check	The optimal sam automatically see "Not available will OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check,	t. h external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language	The optimal sam automatically se 'Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check
Auto range  Beep sound  Sending e-mails  Initialization Self-check	The optimal sam automatically se 'Not available wi OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli	t. h external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display	The optimal sarra automatically set Not available will OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data! Memory check, Japanese, Engli Displays the det	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position	The optimal sarra automatically set Not available will OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data! Memory check, Japanese, Engli Displays the det	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur.
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen	The optimal sarra automatically set Not available with OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data it Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur.
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display	The optimal sarra automatically set Not available with OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli Displays the det Hours, sexagesi ON/OFF Black or white	t. hexternal sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color	The optimal sarra automatically see "Not available win OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data it Memory check, Japanese, Engli Displays the det Hours, sexagesi ON/OFF Black or white Permitted or Noi	t. hexternal sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen	The optimal sar automatically ser Not available win Vota vailable win OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli Displays the det Hours, sexagesi ON/OFF Black or white Permitted or Not *Permitted if set restarted.	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission	The optimal sarra automatically see "Not available win OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data it Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF Black or white Permitted or Not *Permitted of set restarted. * Not permitted S.	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings	The optimal sar automatically ser Not available win OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli Displays the det Hours, sexagesi ON/OFF Black or white Permitted if set restarted. *Not permitted: Set the date and	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission	The optimal sar automatically ser Not available win OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli Displays the det Hours, sexagesi ON/OFF Black or white Permitted if set restarted. *Not permitted: Set the date and	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission Time settings Number of current	The optimal sarra automatically see "Not available win OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data it Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF Black or white Permitted or Not Permitted of Set the date and Up to 9 with con 8971 Current.	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections	The optimal sar automatically se  Not available wi  OFF, Alarm only  Sending e-mails  Sending timing  Sent data  Waveform data i  Memory check,  Japanese, Engli  Displays the det  Hours, sexagesi  ON/OFF  Black or white  Permitted or Not  Permitted: If set  restarted.  Not permitted: Set the date and  Up to 9 with con	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. Itime. mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission Time settings Number of current	The optimal sarra automatically see "Not available will open fall of the property of the prope	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  Ipermitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. It time.  Inbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections	The optimal sarra automatically see "Not available will OFF, Alarm only Sending e-mails Sending timing Sent data  Waveform data i Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF  Black or white Permitted or Not * Permitted or Not * Permitted if set restarted.  Vinto permitted: Set the date and Up to 9 with cor 8971 Current Unit U8977 3ch Current Unit 8973 Logic	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. It time.  mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections	The optimal sarra automatically see "Not available will open fall of the property of the prope	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  Ipermitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. It time.  Inbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission Time settings Number of current sensor connections	The optimal sarra automatically see "Not available will open fall of the programme of the p	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. Itime. mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Supported locations (slots 25 to 27) POWER ON
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections	The optimal sarra automatically see Not available with OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data it Hours, sexagesit ON / OFF Black or white Permitted or Not "Permitted if set restarted." Not permitted: if set restarted. Up to 9 with con 8971 Current Unit UB977 Sch Current Unit Gurrent Unit Green (flashing)	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. Itime. mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Supported locations (slots 25 to 27) POWER ON  Aging in progress (for 30 minutes after the power is turned on)
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color Restart permission  Time settings Number of current sensor connections  Module limitations	The optimal sarra automatically see "Not available will open fall of the property of the prope	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. Itime. mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Supported locations (slots 25 to 27) POWER ON
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections  Module limitations  POWER LED display	The optimal sarra automatically see "Not available will open fall and op	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Attach data values  Dermitted ings are changed during the measuring process, the unit is settings cannot be changed during the measuring process.  It time.  The minimal text of the saved during the measuring process.  Attach data values  Max. 3  Max. 3  Max. 3  Supported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on)  STANDBY (the power switch on the rear is on)  Main power supply is off (the power switch on the rear is off)  Syntax error in command received
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED	The optimal sar automatically ser Not available winder of the North and	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur.  mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process.  time.  mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Supported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on) STANDBY (the power switch on the rear is off) Syntax error in command received "Goes off with a CLS command.
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections  Module limitations  POWER LED display	The optimal sarra automatically see "Not available will open fall and op	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Altach data specified in the main text or files specified by a type of saved data.  Attach data values  Dermitted ings are changed during the measuring process, the unit is settings cannot be changed during the measuring process.  It time.  The minimal text of the saved during the measuring process.  Attach data values  Max. 3  Max. 3  Max. 3  Supported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on)  STANDBY (the power switch on the rear is on)  Main power supply is off (the power switch on the rear is off)  Syntax error in command received
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED	The optimal sarra automatically see Not available with Not available with OFF, Alarm only Sending e-mails Sending timing  Sent data  Waveform data it Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF  Black or white  Permitted or Not ** Permitted if set restarted.  ** Not permitted: If set restarted.  ** Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up to 9 with core set the date and Up	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Alarm and operation, setting initialization, complete initialization  LAN check, media check sh  attach and the sample of the
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED	The optimal sarra automatically see "Not available will open fall of the provided in the provi	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur.  mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process.  time.  mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Max. 3  Supported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on)  STANDBY (the power switch on the rear is on)  Main power supply is off (the power switch on the rear is off)  Syntax error in command received  "Goes off with a CLS command.  Or when a warning occurs  No error or warning  Ambient temperature is too low (< 10°C / 50°F)  Ambient temperature is too low (< 10°C / 50°F)
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED	The optimal sarra automatically see Not available with Not available with OFF, Alarm only Sending e-mails Sending timing  Sent data  Waveform data it Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF  Black or white  Permitted or Not **Permitted for soil **Permitted for Not **Permitted for soil **Perm	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Alarm and operation, setting initialization, complete initialization  LAN check, media check sh  attach and the sample of the
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission  Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED	The optimal sar automatically ser Not available with Not available with OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF Black or white Permitted or Not ** Permitted or Not ** Permitted or Not ** Permitted or Not ** Permitted of Set the date and Up to 9 with cor 8971 Current Unit U8977 3ch Current Unit 8973 Logic Unit Green Green Green Green Red Not on Red Not on Red Purple Yellow Blue	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Alarm and operation, setting initialization, complete initialization LAN check, media check sh  alls of errors and warnings when they occur.  mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process.  Itime.  mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Max. 3  Supported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on)  STANDBY (the power switch on the rear is on)  Main power supply is off (the power switch on the rear is off)  Syntax error in command received  "Goes off with a CLS command.  Or when a warning occurs  No error or warning  Ambient temperature is too high (> 35°C / 95°F)  Ambient temperature is too low (< 10°C / 50°F)  CPU load factor 80% or more  "The average load factor is updated every 0.5 seconds.  The instrument is in the trigger standby state.
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED display	The optimal sarra automatically see "Not available will open fall and the sent continuation of the sent call and the sen	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. Initialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur.  mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. Itime. Initiations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Max. 3  Supported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on) STANDBY (the power switch on the rear is on) Main power supply is off (the power switch on the rear is off) Syntax error in command. Or when a warning occurs No error or warning Ambient temperature is too high (> 35°C / 95°F) Ambient temperature is too low (< 10°C / 50°F) CPU load factor 80% or more  *The average load factor is updated every 0.5 seconds. The instrument is in the trigger standby state. Recording in progress
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED display	The optimal sar automatically ser Not available with Not available with OFF, Alarm only Sending e-mails Sending timing Sent data Waveform data i Memory check, Japanese, Engli Displays the det Hours, sexagesi ON / OFF Black or white Permitted or Not ** Permitted or Not ** Permitted or Not ** Permitted or Not ** Permitted of Set the date and Up to 9 with cor 8971 Current Unit U8977 3ch Current Unit 8973 Logic Unit Green Green Green Green Red Not on Red Not on Red Purple Yellow Blue	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Attach data specified in the main text or files specified by a type of saved data.  Alarm and operation, setting initialization, complete initialization LAN check, media check sh  alls of errors and warnings when they occur.  mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process.  Itime.  mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Max. 3  Supported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on)  STANDBY (the power switch on the rear is on)  Main power supply is off (the power switch on the rear is off)  Syntax error in command received  "Goes off with a CLS command.  Or when a warning occurs  No error or warning  Ambient temperature is too high (> 35°C / 95°F)  Ambient temperature is too low (< 10°C / 50°F)  CPU load factor 80% or more  "The average load factor is updated every 0.5 seconds.  The instrument is in the trigger standby state.
Auto range  Beep sound  Sending e-mails  Initialization Self-check Language Error and warning display Time value display Zero position display Waveform screen background color  Restart permission Time settings Number of current sensor connections  Module limitations  POWER LED display  CMD ERR LED display	The optimal sar automatically sar automatically sar automatically sar Not available with open control of the co	the external sampling Alarm and operation via SMTP Automatic saving, saving with the SAVE operation Attach data specified in the main text or files specified by a type of saved data. nitialization, setting initialization, complete initialization LAN check, media check sh ails of errors and warnings when they occur. mal time, date, data values  permitted ings are changed during the measuring process, the unit is ettings cannot be changed during the measuring process. It ime. mbinations of Current Unit 8971, 3ch Current Unit 8977  Max. 4  Max. 3  Max. 3  Max. 3  Max. 3  May Deported locations (slots 25 to 27)  POWER ON  Aging in progress (for 30 minutes after the power is turned on) STANDBY (the power switch on the rear is on)  Main power supply is off (the power switch on the rear is off) Syntax error in command received "Goes off with a CLS command. Or when a warning occurs  No error or warning Ambient temperature is too high (> 35°C / 95°F) Ambient temperature is too high (> 35°C / 95°F) CPU load factor 80% or more "The average load factor is updated every 0.5 seconds. The instrument is in the trigger standby state. Recording in progress Recording finished. New command received, switches to



## **Option Specifications (sold separately)**

Dimensions/mass: approx. 106 mm (4.17 in) W × 19.8 mm (0.78 in) H × 196.5 mm (7.74 in) D, approx. 250 g (8.8 oz)



ANALOG UNIT 89	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Securacy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for voltage measurement
Input terminals	Isolated BNC connector (input impedance 1 M $\Omega$ , input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 k/500 kHz
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)
Maximum sampling rate	20 MS/s (simultaneous sampling in 2 channels)
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)
Input coupling	AC/DC/GND
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106~mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



4ch ANALOG UNI	T U8975 Warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 4, for voltage measurement	
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	4, 10, 20, 40, 100, 200 V f.s., 6 ranges AC voltage for possible measurement/display: 140 V rms Low-pass filter: 5/500/5 k/200 kHz	
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)	
Maximum sampling rate	5 MS/s (simultaneous sampling in 4 channels)	
Measurement accuracy	±0.1% f.s. (with filter 5 Hz, zero position accuracy included)	
Frequency characteristics	DC to 2 MHz -3 dB	
Input coupling	DC/GND	
Maximum input voltage	200 V DC (the maximum voltage that can be applied across input pins without damage)	

Dimensions/mass: approx. 106~mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



4CH ANALOG UN	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)  year, Post-adjustment accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4, for voltage measurement
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF), Max. rated voltage to ground: 30 V AC or 60 V DC for direct input, 300 V AC, DC (CAT II) when combined with the 9665 (Between each input channel and the main unit, and between the input channels)
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40 V f.s., 9 ranges Low-pass filter: 5/500/5 k/200 kHz
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	5 MS/s (simultaneous sampling in 4 channels)
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 2 MHz -3 dB
Input coupling	DC/GND
Maximum input voltage	40 V DC (with direct input), 400 V DC (with 9665)

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 260 g (9.2 oz) Accessories: None



DIGITAL VOLTMI MR8990	ETER UNIT  (Accuracy at 23 ±5°C/73 ±9°F, 80% RH after 30 minutes of warm- up time and calibration, Accuracy guaranteed for 1 year, Post- adjustment accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for DC voltage measurement	
Input terminals	Banana input connectors (Input impedance: 100 M $\Omega$ or higher with 100 mV f.s. to 10 V f.s. range, otherwise 10 M $\Omega$ )	
	Max. rated voltage to ground: $300 \text{ V}$ AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	100, 1000 mV f.s. 10, 100, 1000 V f.s., 5 ranges	
Measurement resolution	1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)	
Integration time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)	
Response time	2 ms +2 x integration time or less (rise - f.s. $\rightarrow$ + f.s., fall + f.s. $\rightarrow$ - f.s.)	
Basic measurement accuracy	±0.01% rdg. ±0.0025% f.s. (at range of 1000 mV f.s.)	
Maximum input voltage	500 V DC (the maximum voltage that can be applied across input pins without damage)	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



DIGITAL VOLTME	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80 % RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 4, for DC voltage measurement	
	Isolated BNC connectors (Input impedance: 100 M $\Omega$ or higher with 1 V f.s. to 10 V f.s. range, otherwise 10 M $\Omega)$	
Input terminals	Max. rated voltage to ground: 100 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	1, 10, 100 V f.s., 3 ranges	
Measurement resolution	1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)	
Integration time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)	
Basic measurement accuracy	±0.02% rdg. ±0.0025% f.s.	
Maximum input voltage	100 V DC (the maximum voltage	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



DC/RMS UNIT 897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable		
Input terminals	Isolated BNC connector (input impedance $1 M\Omega$ , input capacitance $30  pF$ ) Max. rated voltage to ground: $300  V  AC$ , DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 550/500/5 k/100 kHz		
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)		
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)		
RMS measurement	RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz) ±3% f.s. (1 kHz to 100 kHz) Response time: SLOW 5 s (rise time from 0 to 90% of full scale), MID 800 ms (rise time from 0 to 90% of full scale), FAST 100 ms (rise time from 0 to 90% of full scale) Crest factor: 2		
Frequency characteristics	DC to 400 kHz -3 dB (with AC coupling: 7 Hz to 400 kHz -3 dB)		
Input coupling	AC/DC/GND		
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)		

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



HIGH RESOLUTI 8968	ON UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement		
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 KHz		
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)		
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)		
Frequency characteristics	DC to 100 kHz -3 dB (with AC coupling: 7 Hz to 100 kHz -3 dB)		
Input coupling	AC/DC/GND		
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)		

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



Accessories. Notic				
3CH CURRENT UN U8977	IIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)			
Measurement functions	No. of channels: 3, Current measurement with optional current sensor			
Input terminals	Dedicated connector terminal (ME15W) (input impedance 1 MΩ, common GND with recorder)			
Compatible current sensors	9272-05, CT6841-05, CT6843-05, CT6844-05, CT6845-05, CT6846-05, CT6862-05, CT6863-05, 9709-05, CT6904, CT6865-05, CT6875, CT6876 (Direct connection) CT7631, CT7636, CT7642, CT7731, CT7736, CT7742, CT7044, CT7045, CT7046 (Connection using optional CONVERSION CABLE CT9920)			
Measurement range	- Directly connected current sensor: Automatically identify rating of compatible current sensors Using 9272-05 (20 A), CT6841-05: 2 A to 100 A f.s., 6 ranges Using CT6862-05: A to 200 A f.s., 6 ranges Using CT6862-05: CT6845-05, CT6863-05: 20 A to 1000 A f.s., 6 ranges Using 9272-05 (200 A), CT6843-05, CT6863-05: 20 A to 1000 A f.s., 6 ranges Using CT6846-05, CT6845-05, CT6876: 80 A to 4000 A f.s., 6 ranges Using CT6846-05, CT6865-05, CT6876: 80 A to 4000 A f.s., 6 ranges Current sensors connected using CT9920: Select conversion rate or model Using CT7631, CT7731: 200 A, 1 range Using CT7636, CT7736: 200 A to 1000 A, 3 ranges Using CT7642, CT7742: 2000 A/4000 A, 2 ranges Using CT7642, CT7742: 2000 A/4000 A, 2 ranges Using CT7644, CT7045, CT7046: 2000 A to 10.000 A, 3 ranges			
Measurement accuracy (with 5 Hz filter ON) Note: Add the accuracy and attributes of the current sensor being used.	±0.3% f.s. Frequency characteristics: DC to 2 MHz ±3 dB			
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)			
Maximum sampling rate	5 MS/s (simultaneous sampling in 3 channels)			
Other functions	Input coupling: DC/GND, Low-pass filter: 5/500/5 k/200 kHz			

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: CONVERSION CABLE 9318  $\times$  2 (To connect the current sensor to the 8971)



CURRENT UNIT 8	971 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year, Postadjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, Current measurement with optional current sensor		
Input terminals	Sensor connector (input impedance 1 MΩ, exclusive connector for current sensor via the CONVERSION CABLE 9318, common GND with recorder)		
Compatible current sensors	CT6862, CT6863, 9709, CT6865, CT6841, CT6843, CT6844, CT6845, CT6846, 9272-10 (To connect to the 8971 via the CONVERSION CABLE 9318)		
Measurement range	Using 9272-10 (20 A), CT6841: 2 A to 100 A f.s., 6 ranges Using CT6862: 4 A to 200 A f.s., 6 ranges Using 9272-10 (200 A), CT6843, CT6863: 20 A to 1000 A f.s., 6 ranges Using CT6844, CT6845, 9709, CT6846*1, CT6865*1: 40 A to 2000 A f.s., 6 ranges *1: The conversion ratio needs to be set to 2 for scaling.		
Measurement accuracy (with 5 Hz filter ON) * Note: Add the accuracy and attributes of the current sensor being used.	±0.65% f.s.  RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 10 kHz)  RMS response time: 100 ms (rise time from 0 to 90% of full scale)  Crest factor: 2  Frequency characteristics: DC to 100 kHz±3 dB (with AC coupling: 7 Hz to 100 kHz)		
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)		
Other functions	Input coupling: AC/DC/GND, Low-pass filter: 5/50/500/5 k/50 kHz		

Dimensions/mass: approx. 106~mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230~g (8.1 oz) Accessories: None



(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80° warm-up time and zero adjustment; Ac year, Post-adjustment accuracy guaran **HIGH-VOLTAGE UNIT U8974** No. of channels: 2, for voltage measurement, DC/RMS selectable Max. rated voltage to ground: 1000 V AC, DC for measurement category III, 600 V AC, Measurement functions DC for measurement category IV Banana input terminal (Input impedance: 4 MΩ, Input capacitance: 5 pF) Input terminals 4, 10, 20, 40, 100, 200, 400, 1000 V f.s. (DC mode), 8 ranges 10, 20, 40, 100, 200, 400, 1000 V f.s. (RMS mode), 7 ranges Measurement range Low-pass filter: 5/50/500/5 k/50 kHz Measurement resolution 1/32,000 of measurement range (using 16-bit A/D conversion) Maximum sampling rate 1 MS/s ±0.25% f.s. (with filter 5 Hz, zero position accuracy included) Measurement accuracy RMS accuracy: ±1.5% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 100 kHz) Response time: High speed 150 ms, medium speed 500 ms, low speed 2.5 s RMS measurement Frequency characteristics DC to 100 kHz -3 dB Input coupling DC/GND Maximum input voltage 1000 V DC, 700 V AC

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 245 g (8.6 oz) Accessories: CONVERSION CABLE L9769  $\times$ 2 (Cable length: 60 cm)

Accessories. CONVERSION CABLE 19769 ×2 (Cable length: 60 cm)		
STRAIN UNIT U89	(Accuracy at 23 ±5°C/73 ±0°F, 80% RH or less after 30 minutes of warm-up time and auto-balance; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for distortion measurement (electronic auto-balancing, balance adjustment range within $\pm 10,000~\mu \epsilon$ or less)	
Input terminals	NDIS connector EPRC07-R9FNDIS (via CONVERSION CABLE L9769: NDIS connector PRC03-12A10-7M10.5)	
	Max. rated voltage to ground: 30 V AC rms or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage)	
Suitable transducer	Strain gauge converter, Bridge impedance: 120 $\Omega$ to 1 k $\Omega$ , Bridge voltage: 2 V $\pm 0.05$ V, Gauge rate: 2.0	
Measurement range	400, 1000, 2000, 4000, 10,000, 20,000 με f.s., 6 ranges Low-pass filter: 5/10/100/1 kHz	
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)	
Maximum sampling rate	200 kS/s (simultaneous sampling in 2 channels)	
Measurement accuracy After auto-balancing	$\pm 0.5\%$ f.s. $\pm 4 \mu\epsilon$ (5 Hz filter ON)	
Frequency characteristics	DC to 20 kHz +1/-3 dB	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  204.5 mm (8.05 in) D, approx. 240 g (8.5 oz) Accessories: Ferrite clamp  $\times$  2



TEMP UNIT 8967	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm- up time and zero adjustment; Accuracy guaranteed for 1 year, Post- adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for temperature measurement with thermocouple (voltage measurement not available)		
Input terminals	Thermocouple input: Push-button terminal block, Recommended wire diameter: single-wire 0.14 to 1.5 mm², braided wire 0.14 to 1.0 mm² (conductor wire diameter $\phi$ 0.18 mm or more), AWG 26 to 16 Input impedance: min. 5 $M\Omega$ (with line fault detection ON/OFF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Temperature measurement range Note: Upper and lower limit values depend on the thermocouple	200°C (392°F) f.s. (-100°C to 200°C (-148°F to 392°F)), 1000°C (1832°F) f.s. (-200°C to 1000°C (-328°F to 1832°F)), 2000°C (3632°F) f.s. (-200°C to 2000°C (-328°F to 3632°F)), 3 ranges Measurement resolution: 1/20,000 of measurement range (using 16-bit A/D conversion)		
Thermocouple range (JIS C 1602-1995) (ASTM E-988-96)	K: -200°C to 1350°C (-328°F to 2462°F), R: 0°C to 1700°C (32°F to 3092°F), J: -200°C to 1100°C (-328°F to 2012°F), S: 0°C to 1700°C (32°F to 3092°F), E: -200°C to 800°C (-328°F to 1472°F), B: 400°C to 1800°C (752°F to 3272°F), W (WRe5-26): 0°C to 2000°C (32°F to 3632°F) W (WRe5-26): 0°C to 2000°C (32°F to 3632°F)		
	Reference junction compensation: internal/external (switchable), line fault detection ON/OFF possible		
Data refresh rate	3 methods, Fast: 1.2 ms (digital filter OFF), Normal: 100 ms (digital filter 50/60 Hz), Slow: 500 ms (digital filter 10 Hz)		
Measurement accuracy	Thermocouple K, J, E, T, N: ±0.1% f.s. ±1°C (±1.8°F), (±0.1% f.s. ±2°C (±3.6°F) at -200°C to 0°C (-328°F to 32°F))  Thermocouple R, S, B, W: ±0.1% f.s. ±3.5°C (±6.3°F) (at 0°C (32°F) to less than 400°C (752°F); However, no accuracy guarantee at less than 400°C (752°F) for B), ±0.1% f.s. ±3°C (±5.4°F) (at 400°C (752°F) or more)  Reference junction compensation [RJC] accuracy: ±1.5°C (±2.7°F) (added to measurement accuracy with internal reference junction compensation)		

Dimensions/mass: approx.  $106 \text{ mm} (4.17 \text{ in}) \text{ W} \times 19.8 \text{ mm} (0.78 \text{ in}) \text{ H} \times 196.5 \text{ mm} (7.74 \text{ in}) \text{ D, approx. } 250 \text{ g} (8.8 \text{ oz})$ 



FREQ UNIT 8970	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80 % RH after 30 minutes of warm- up time; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage input based frequency measurement, rotation, power frequency, integration, pulse duty ratio, pulse width		
Input terminals	Isolated BNC connector (input impedance 1 MΩ, input capacitance 30 pF), Max, rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Frequency mode	Measurement range: Between DC to 100 kHz (minimum pulse width 2 µs), 20 Hz to 100 kHz fs., 8 ranges  Accuracy: ±0.7% fs. (sexclude 100 kHz range), ±0.7% fs. (100 kHz range)		
Rotation mode	Measurement range: Between 0 to 2 million rotations/minute (minimum pulse width 2μs), 2 kr/min to 2 Mr/min f.s., 7 ranges Accuracy: ±0.1% f.s. (exclude 2 Mr/min range), ±0.7% f.s. (2 Mr/min range)		
Power frequency mode	Measurement range: 50 Hz (40 to 60 Hz), 60 Hz (50 to 70 Hz), 400 Hz (390 to 410 Hz), 3 ranges Accuracy: ±0.03 Hz (50, 60 Hz), ±0.1 Hz (400 Hz range)		
Integration mode	Measurement range: 40 k-counts f.s. to 20 M-counts f.s. 6 ranges Accuracy: ±0.0025% f.s.		
Duty ratio mode	Measurement range: Between 10 Hz to 100 kHz (minimum pulse width 2 μs), 100% f.s. Accuracy: ±1% (10 Hz to 10 kHz), ±4% (10 kHz to 100 kHz)		
Pulse width mode	Measurement range: Between 2 μs to 2 s, 10 ms to 2 s f.s. Accuracy: ±0.1% f.s.		
Measurement resolution	0.0025% f.s. (integration mode), 0.01% f.s. (exclude integration, power frequency mode), 0.01 Hz (power frequency mode)		
Input voltage range and threshold level	±10 V to ±400 V, 6 ranges, selectable threshold level at each range		
Other functions	Slope, Level, Hold, Smoothing, Low-pass filter, Switchable DC/AC input coupling, Frequency dividing, Integration over-range keep/return		

Dimensions/mass: approx. 106~mm (4.17 in) W imes 19.8 mm (0.78 in) H imes 196.5 mm (7.74 in) D, approx. 190 g (6.7 oz) Accessories: None



LOGIC UNIT 8973	
Measurement functions	No. of channels: 16 channels (4 ch/1 probe connector × 4 connectors)
	Mini DIN connector (for HIOKI logic probes only) Compatible logic probes: 9320-01, 9327, MR9321-01

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



CHARGE UNIT U897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for acceleration measurement		
	Voltage input / pre-amp embedded input: Metal BNC connector (Under voltage input: input impedance 1 MQ, input capacitance 200 pF or less) Charge input, Miniature connector (#10-32UNF)		
Input terminals	Max. rated voltage to ground: $30\ V\ AC$ or $60\ V\ DC$ (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input		
	channels without damage)  *Voltage input terminal GND and charge input terminal GND for the same channel are shared.		
Suitable transducer	Charge output type acceleration detector Pre-amp embedded acceleration detector		
Measurement range Charge input (Miniature connector) Pre-amp embedded input (BNC connector)	1 (m/s²) to 200 k (m/s²) f.s., 12 ranges x 6 types Charge input sensitivity: 0.1 to 10 pC /(m/s²) Pre-amp embedded sensor input sensitivity: 0.1 to 10 mV /(m/s²) Amplitude accuracy: ±2% f.s. Frequency characteristics: 1(1.5) to 50 kHz -3 dB (charge input) Low-pass filter: 500 fs.Hz Pre-amp supply power: 3.5 mA ±20%, 22 V ±5% Maximum input charge: ±500 pC (6 ranges on high sensitivity side), 50.000 pC (6 ranges on low sensitivity side)		
Measurement range Voltage input (BNC connector)	10 mV to 40 V f.s., 12 ranges, DC amplitude accuracy: ±0.5% f.s. Frequency characteristics: DC to 50 kHz -3 dB (with DC coupling), 1 Hz to 50 kHz -3 dB (with AC coupling) Low-pass filter: 5/500/5 kHz, input coupling: AC/DC/GND		
	Maximum input voltage: 40 V DC		
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	200 kS/s		
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)		
TEDS	IEEE 1451.1.4 class 1 support (Support for sensor information reading and automatic sensitivity setting)		

Dimensions/mass: approx. 106~mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230~g (8.1 oz) Accessories: None



WAVEFORM GEN MR8790	ERATOR UNIT	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)
Output terminal	No. of channels: 4, SMB terminal (Output impedance: 1 Ω or less) Max. rated voltage to ground: 33 V rms AC or 70 V DC	
Output voltage range	-10 V to 10 V (Amplitude setting range: 0 V to 20 V p-p, Setting resolution: 1 mV)	
Max. output current	5 mA	
Output function	DC, Sine wave (Output frequency range: 0 Hz to 20 kHz)	
Accuracy	Amplitude accuracy: ±0.25% of setting ±2 mV p-p (1 Hz to 10 kHz)  Offset accuracy: ±3 mV  DC output accuracy: ±0.6 mV	
Other	Self-test function (Voltage, Current)	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



PULSE GENERA	TOR UNIT MR8791	(Accuracy at 23 $\pm 5^{\circ}\text{C}/73~\pm 9^{\circ}\text{F},~80\%$ RH or less with no condensation; accuracy guaranteed for 1 year)
Output terminal	No. of channels: 8, Connector: SCSI-2, half pitch, 50-pin Max. rated voltage to ground: 33 V rms AC or 70 V DC (between unit and output channels) Logic output/Open collector output	
Output mode 1	Pattern output: Read frequency: 0 Hz to 120 kHz, 2048 logic patterns	
Output mode 1	Pulse output: Frequency 0 Hz to 20 kHz, Duty 0.1% to 99.9%	
Output mode 2	Logic output: Output voltage lo (H level: 3.8 V or more, L level: 0.	
	Open collector output: Absolute maximum rated voltage for collector/emitter 50 V Overcurrent protection: 100 mA	
Other	Self-test function	

Dimensions/mass: approx. 106~mm (4.17 in) W imes 19.8 mm (0.78 in) H imes 196.5 mm (7.74 in) D, approx. 280~g (9.9 oz) Accessories: None



Accessories:	None	
VIR GENERATO	R UNIT U8794	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH or less with no condensation; accuracy guaranteed for 1 year)
Output terminal	No. of channels: 8 (each channels) Max. rated voltage to ground	el is isolated), Connector: 25-pin D-sub : 25 V
Output items	DC voltage, DC current, resistance (simulated output)	
	DC voltage: -0.100 0 V to +5.300 0 V (setting resolution: 0.1 mV)	
Output range	DC current: 5 mA range: -5.000 0 mA to +5.000 0 mA, Setting resolution: 0.1 $\mu$ A 1 mA range: -1.000 00 mA to +1.000 00 mA, Setting resolution: 0.01 $\mu$ A 250 $\mu$ A range: -250.00 $\mu$ A to +250.00 $\mu$ A, Setting resolution: 0.01 $\mu$ A 50 $\mu$ A range: -50.000 $\mu$ A to +50.000 $\mu$ A, Setting resolution: 0.001 $\mu$ A	
	Resistance: 10 \Omega to 1 M\Omega, Setting resolution: 6 digits	
Output accuracy	DC voltage: 5 V range, ±0.035% of setting ± 800 μV  DC current: 5 mA range: ±0.050% of setting ± 4.0 μA 1 mA range: ±0.050% of setting ± 800 nA 250 μA range: ±0.050% of setting ± 200 nA 50 μA range: ±0.050% of setting ± 40 nA	
Other	Self diagnostic, switch outpu	t terminals, estimate target connection, cancel offset

### **System Chart of Options**

## Model: MEMORY HICORDER MR8740T Model No. (Order code) (Specifications) MR8740-50 (Main unit only, install up to 27 optional modules) Note: The main unit cannot operate alone You must install one or more optional modules in the unit.

#### Storage media

'Use only the storage media sold by HIOKI. Compatibility and performance are not quaranteed for storage media made by other manufacturers. You may be read from or save data to such media



USB DRIVE Z4006 16 GB Using highly durable and reliable

SLC flash memory

#### PC Software (free)



Waveform Viewer Wv

Software for checking waveforms with binary data on a PC, saving data in CSV format, and transferring to spreadsheet programs

Operating environment Windows 10/8/7 (32/64-bit) Functions:

- Simple display of waveform files
   Convert binary data files to text format, CSV, etc.
- Scroll function, enlarge/reduce display, jump to cursor/trigger position, etc.



WAVE PROCESSOR 9335

PC display for massive amounts of waveform data and more

## Logic signal measurement



LOGIC PROBE 9327 4-channel type, for voltage/contact signal ON/ OFF detection (response pulse width 100 ns or more, miniature terminal type)



LOGIC PROBE MR9321-01 4 isolated channels, ON/OFF detection of AC/ DC voltage (miniature terminal type)

LOGIC PROBE 9320-01 4-channel type, for voltage/contact signal ON/ OFF detection (response pulse width 500 ns or more, miniature terminal type)



**Output cable** 



CONNECTION CABLE L9795-01

Max. rated voltage to ground: 33 V AC rms or 70 V DC SMB terminal - alligator clip Cable length: 1.5 m (4.92 ft)



CONNECTION CABLE L9795-02

Max. rated voltage to ground 33 V AC rms or 70 V DC SMB terminal - BNC terminal Cable length: 1.5 m (4.92 ft)

Input modules

Input cords not included. Please purchase them separately. When using the 9709 with CURRENT UNIT 8971, up to a total of



ANALOG UNIT 8966 2 ch, voltage input, 20 MS/s, (DC to 5 MHz)



4ch ANALOG UNIT U8975

4 ch, voltage input, 5 MS/s, (DC to 2 MHz)



4CH ANALOG UNIT U8978

4 ch, voltage input, 5 MS/s, (DC to 2 MHz), highest sensitivity range 100 mV f.s.



HIGH RESOLUTION UNIT 8968 2 ch, voltage input, 1 MS/s (DC to 100 kHz)



DC/RMS UNIT 8972

2 ch, voltage/1 MS/s, (DC to 400 kHz) RMS rectifier (DC, 30 to 100 kHz) HIGH-VOLTAGE UNIT U8974



2 ch, voltage input, max. 1000 V DC and 700 V AC

DIGITAL VOLTMETER UNIT MR8990 2 ch, high-precision DC voltage, 0.1  $\mu V$  resolution, maximum sampling rate 500 times/s



DIGITAL VOLTMETER UNIT U8991 4 ch, high-precision DC voltage, 1 µV resolution, maximum sampling rate 50 times/s



**CURRENT UNIT 8971** 

2 ch, for measuring current using dedicated current sensors, 2 CONVERSION CABLES 9318 included, for use with up to 4 units



3CH CURRENT UNIT U8977

3 ch, for measuring current using dedicated current sensors, can be directly connected to ME15W (12-pin) connector-type sensors, for use with up to 3 units



TEMP UNIT 8967

2 ch, thermocouple temperature input



STRAIN UNIT U8969

2 ch, strain gauge type converter amp





FREQ UNIT 8970 2 ch. for measurement of frequency, RPM, pulse, etc.



2 ch, for acceleration measurement, supports charge output, pre-amp output, and voltage output



LOGIC UNIT 8973

4 terminals, 16 ch, up to 3 units (slots 25 to 27 only)

Output modules

\* Output cords not included. Please purchase them separately \* Configure settings with communication commands.

WAVEFORM GENERATOR UNIT MR8790 4ch, DC output ±10 V, Sine wave output 1 Hz to 20 kHz



PULSE GENERATOR UNIT MR8791 8ch, Pulse output 0.1 Hz to 20 kHz, Pattern output





VIR GENERATOR UNIT U8794

8ch, DC voltage output, DC current output, resistance output (simulated resistance)

#### SCI Monitor 4.0





HSCI-4.0-SENT HSCI-4.0-LIN

CAN monitors, LIN monitors, and SENT monitors that are the same size as the MR8740T unit can be purchased from Nihon System Eight Co., Ltd. Power is supplied to a monitor when it is installed on the MR8740T. Note that it will not be possible to record or analyze the data with the MR8740T or HIOKI software. Please contact Nihon System Eight for additional information http://nse-inc.co.jp/

\* Voltage is limited to the specifications of the **INPUT CORD (A)** CONNECTION CORD L9790

Flexible φ 4.1 mm (0.16 in) thin cable allowing for up to 600 V ir 1.8 m (5.91 ft) length \* The end clip is sold separately.

ALLIGATOR CLIP L9790-01

Red/black set attaches to the ends of the cables L9790 GRABBER CLIP 9790-02

\* When this clip is attached to the end of the L9790, input is limited to CAT II 300 V. Red/black set.

CONTACT PIN 9790-03 Red/black set attaches to the ends of the cables L9790

Voltage is limited to the specifications of th input modules in use. INPUT CORD (B)

CONNECTION CORD L9198 φ 5.0 mm (0.20 in) dia., cable allowing for up to 300 V input, 1.7 m (5.58 ft) length, small alligator clip

CONNECTION CORD L9197  $\phi$  5.0 mm (0.20 in) dia., cable allowing for up to 600 V input, 1.8 m (5.91 ft) length, detachable large alligator clips are bundled

GRABBER CLIP 9243

Attaches to the tip of the L9197, red/black set, full length: 196 mm (7.72 in)

Voltage is limited to the specifications of th input modules in use.

10:1 PROBE 9665 Max. rated voltage to ground is same as for input module, max. input voltage 1 kV rms (up to 500 kHz), 1.5 m (4.92 ft) length

INPUT CORD (C)

INPUT CORD (E)

INPUT CORD (G)

100:1 PROBE 9666 Max. rated voltage to ground is same as for input module, max. input voltage 5 kV peak (up to 1 MHz), 1.5 m (4.92 ft) length

Voltage to ground is within this product's specifications. \*Separate power source is also INPUT CORD (D) DIFFERENTIAL PROBE P9000-01

(Wave Only) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz DIFFERENTIAL PROBE P9000-02

(Switch between Wave/RMS) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz

AC ADAPTER Z1008 100 to 240 V AC

Voltage to ground is within this product's specifications. \*Separate power source is also

**DIFFERENTIAL PROBE 9322** AC, 2 kV DC, Frequency bands

AC ADAPTER 9418-15 100 to 240 V AC

INPUT CORD (F)

CONNECTION CABLE L4940 Banana plug - banana plug, Cord length 1.5 m (4.92 ft)

EXTENSION CABLE L4931 Extend the length of banana plug cables, Cable length: 1.5 m (4.92 ft)

ALLIGATOR CLIP L4935 Attach to the tip of banana plug cables, CAT IV 600 V, CAT III 1000 V

BUS BAR CLIP L4936 Attach to the tip of banana plug cables, CAT III 600 V

MAGNETIC ADAPTER L4937 Attach to the tip of banana plug cables, CAT III 1000 V

GRABBER CLIP 9243 Attach to the tip of banana plug cables, red/black set, full length: 196 mm (7.72 in), CAT III 1000 V

> \* For the MR8990 \*Voltage is limited to the specifications of the input modules in use. TEST LEAD L2200

Cable length: 70 cm, tips interchangeable with a pin test lead or alligator clip, maximum input voltage: CAT IV 600 V, CAT III 1000 V

High-precision current measurement \*ME15W (12-pin) terminal type \*Directly connect to U8977



CI AMP ON SENSOR 9272-05, 100 kHz, 200 A

High-precision pull-through current sensors, observe waveforms from DC to distorted AC AC/DC CURRENT SENSOR CT6875, 2 MHz, 500 A

AC/DC CURRENT SENSOR CT6876, 1.5 MHz, 1000 A Observe waveforms from DC to distorted AC AC/DC CURRENT PROBE CT6844-05, 200 kHz, 500 A AC/DC CURRENT PROBE CT6845-05, 100 kHz, 500 A AC/DC CURRENT PROBE CT6846-05, 20 kHz, 1000 A

Precautions when connecting the CURRENT UNIT 8971 with a high-precision current sensor

 High-precision current sensor (ME15W) + CT9901 + 9318 → CURRENT UNIT 8971 High-precision current sensor (ME15W) + CT955x + BNC cable → ex CURRENT UNIT 8971

CURRENT UNIT 89/1 High-precision current sensor (PL23) + 9318 → CURRENT UNIT 8971 High-precision current sensor (PL23) + CT9900 + CT955x + BNC cable → except CURRENT UNIT 8971

The 9318 is bundled with the CURRENT UNIT 8971.

ine the high-precision current sensor and the power supply 55) to perform current measurements with a voltage input unit. Insors with ME15W (12-pin) terminals (-05 type) can be connec

The separately available CONVERSION CABLE CT9900 is required in orde to use a sensor with a PL23 (10-pin) terminal.

POWER SUPPLY for Sensors SENSOR UNIT CT9555 1 ch, with waveform output

CONNECTION CORD L9217 Both cord ends are isolated BNC, 1.6 m (5.25 ft) PL23 (10-pin) - ME15W (12-pin) conversio

CONVERSION CABLE CT9900 Convert PL23 (10-pin) terminal to ME15W (12-pin) terminal

y available CONVERSION CABLE CT9901 is required in high-precision current sensor equipped with a ME15W all (-05 type) with the CURRENT UNIT 8971. 55x is not required in order to use a sensor equipped with it is not required in order to use a sensor equipped with it is the sensor captured for that setup.

ME15W (12-pin) - PL23 (10-pin) conversion

CONVERSION CABLE CT9901
Convert ME15W (12-pin) terminal to PL23 (10-pin) terminal

Other current sensor types

The MEMORY HICORDER can be used with various types of current sensors and probes

U8977 only

#### 10 mA class to 500 A (High speed)



CLAMP ON PROBE 3273-50 Frequency characteristics: DC to 50 MHz wideband response, 10 mA-class up to 30 A rms

CLAMP ON PROBE 3276 Frequency characteristics: DC to 100 MHz wideband response, 10 mA-class up to 30 A rms

CLAMP ON PROBE 3274 Frequency characteristics: DC to 10 MHz

wideband response, up to 150 A rms CLAMP ON PROBE 3275 Frequency characteristics: DC to 2 MHz

wideband response, up to 500 A rms

Custom cable For P9000. Inquire with your local Hioki distributor.

(1) Bus powered USB cable (2) USB(A)- Micro B cable (3) 3-prong cable

### Non-contact voltage measuring



NON-CONTACT AC VOLTAGE PROBE SP3000-01 5 V rms rated, 10 Hz to 100 kHz band width



NON-CONTACT AC VOLTAGE PROBE

SP3000 Sold individually AC VOLTAGE PROBE SP9001 Sold individually

## Other options for input



CONNECTION CORD L9217 Cord has insulated BNC connectors at both ends, signal output use, 1.6 m (5.25 ft) length

CONVERSION ADAPTER 9199
Receiving side banana terminal, output BNC terminal

#### Temperature sensor



THERMOCOUPLE For reference only. Please purchase locally.

#### General-purpose current measurement \*PL14 terminal type AC/DC AUTO 7FRO CURRENT SENSOR CT 7731

DC, 1 Hz to 5 kHz, 100 A AC/DC AUTO ZERO CURRENT SENSOR CT7736

DC, 1 Hz to 5 kHz, 600 A AC/DC AUTO ZERO CURRENT SENSOR CT7742 DC, 1 Hz to 5 kHz, 2000 A

AC/DC CURRENT SENSOR CT7631 DC, 1 Hz to 10 kHz, 100 A

AC/DC CURRENT SENSOR CT7636 DC. 1 Hz to 10 kHz. 600 A

AC/DC CURRENT SENSOR CT7642 DC, 1 Hz to 10 kHz, 2000 A

AC FLEXIBLE CURRENT SENSOR CT7044 100 mm (3.94 in), 6000 A

AC FLEXIBLE CURRENT SENSOR CT7045 180 mm (7.09 in), 6000 A

AC FLEXIBLE CURRENT SENSOR CT7046 254 mm (10.00 in), 6000 A

eparately available CONVERSION CABLE CT9920 is red in order to connect a PL14 terminal general-purpose nt sensor to the CURRENT UNIT U8977.

## PL14 - ME15W (12-pin) conversion



CONVERSION CABLE CT9920 Convert PL14 terminal to ME15W (12-pin) terminal

### Leak Current \*For commercial power lines, 50/60 Hz



CLAMP ON LEAK HITESTER 3283 10 mA range / 10 µA resolution to 200 A range, with monitor / analog output 1 V f.s.

**OUTPUT CORD L9095** Connect to BNC terminal, 1.5 m (4.92 ft) length

AC ADAPTER 9445-02 100 to 240 V AC, 9 V/ 1 A

#### Precautions for connecting current sensors and current probes

\*Depending on the combination of current sensors and current probes, physical and space limitations may prevent simultaneous connection. Hioki can assist with special order conversion cables please inquire with your local distributor.

\*A total of 9 current sensors and current probes can be connected simultaneously to the Memory HiCorder. (Total with the CURRENT UNIT U8977, CURRENT UNIT 8971, and PROBE POWER UNIT Z5021 connected)

\*Three U8977 current units and four 8971 current units can be simultaneously connected to the Memory

\*Only the U8977 can use the CT9920 to convert a PL14 connector sensor. The 8971 does not support this combination.

### INPUT CORD (H)




CONNECTION CORD 9166 BNC - clip, Cord length: 1.5m (4.92 ft)





e-mail : tem@es-france.com Site Web : www.es-france.co





# The MR8740T supports your testing technologies with simultaneously sampled measurements across multiple channels.







### Set examples

### Multi-channel measurement for ECU development

In addition to the measurement of 68 analog channels + 24 logic channels, the MR8740T can also generate waveforms on 4 channels, generate pulses on 8 channels, and output DC voltage/DC current/ simulated resistance on 40 channels. This allows the simultaneous testing of multiple points, such as for high-performance boards, with a single unit.

MEMORY HICORDER	MR8740-50	1 unit
4ch ANALOG UNIT	U8975	17
CONNECTION CORD	L9790	68
ALLIGATOR CLIP	L9790-01	68
WAVEFORM GENERATOR UNIT	MR8790	1
CONNECTION CABLE	L9795-01	4
PULSE GENERATOR UNIT	MR8791	1
VIR GENERATOR UNIT	U8794	5
LOGIC UNIT	8973	3
LOGIC PROBE	9327	3

### Support for a wide range of multi-channel measurements

High speed, isolation, and high precision are achieved even with multi-channel measurement.

High-speed isolated recording across 108 channels at 5 MS/s

MEMORY HICORDER	MR8740-50	1 unit
4ch ANALOG UNIT	U8975	27
CONNECTION CORD	L9790	108
ALLIGATOR CLIP	L9790-01	108

 $High-precision\ voltage\ measurements\ across\ 108\ channels\ at\ a\ sampling\ rate\ of\ 50\ times/s$ 

MEMORY HICORDER	MR8740-50	1 unit
DIGITAL VOLTMETER UNIT	U8991	27
CONNECTION CORD	L9790	108
ALLIGATOR CLIP	L9790-01	108

Multi-channel strain measurements across 54 channels with a strain gauge converter

MEMORY HICORDER	MR8740-50	1 unit
STRAIN UNIT	U8969	27
CONVERSION CABLE	L9769	54