

XLR Plug




Package case



AWA6160 ear simulator
IEC 60318-1

Items
①AWA6160 coupler (2.5CC)
②Fixed mount
③: AWA14424C Mic. (h:16.5mm) 20Hz~16kHz
④AWA14604 Preamplifier(Standard
⑤Plate
⑥5N Jig
Package case

Note: normal extension cable for AWA14604 preamplifier is BNC plug, if need to use AWA 14604 preamp connects with sound card (with XLR plug, 48 volt Phantom power), please buy an extension cable with XLR plug.



XLR Plug


Package case



AWA6162 ear simulator
IEC 60711

Items	
①	Fixed mount
②	AH14424 Mic (h:13mm) 10Hz~20kHz
③	AWA14604 preamplifier
④	5N Jig
⑤	AWA6162 coupler (1.26 CC)
Package case	

Note: normal extension cable for AWA14604 preamplifier is BNC plug, if need to use AWA 14604 preamp connects with sound card (with XLR plug, 48 volt Phantom power), please buy an extension cable with XLR plug.



Package case




AWA6161 ear simulator
IEC 60318-5

XLR Plug



Items
①Fixed mount
②AWA14422D Mic (h:16mm)
③AWA14604 Preamplifier
④5N Jig
⑤AWA6161 coupler 2cm ³
Package case

Note: normal extension cable for AWA14604 preamplifier is BNC plug, if need to use AWA 14604 preamp connects with sound card (with XLR plug, 48 volt Phantom power), please buy an extension cable with XLR plug.



XLR Plug

Package case



AWA6163 ear simulator
IEC60318-3

Items
①Fixed mount
②AWA14412 Mic 1 inch
③AWA14604 preamplifier
④5N Jig
⑤AWA6163 coupler 6cm³
Package case



Note: normal extension cable for AWA14604 preamplifier is BNC plug, if need to use AWA 14604 preamp connects with sound card (with XLR plug, 48 volt Phantom power), please buy an extension cable with XLR plug.