ACCESSORIES FOR ARTIFICIAL EARS & MOUTHS

IEC60318-5 1" 2cc Coupler-Accessories for Testing of ITE Hearing Aids

GR0316 Union nut **RA0017** 1/2" to 1" Adapter **GR0723 RA0114 Tube Adapter** 1/4"-button Adapter **OR5003** 0-ring **RA0115** In-ear Adapter OR5389 0-ring



















RA0017

For testing of ITE hearing aids with an RA0113 1" IEC60318-5 Ear Simulator, the items shown above are needed. The Ilustration to the right shows the context in which they

GRAS RA0052

are needed.

Test Jiq



For use with GRAS couplers and ear simulators. It has an adjustable spring-loaded arm to exert a variable force on the test object.

GRAS RA0058

1/2" to 1" Microphone Adapter



Converts a 1/2" microphone (with grid removed) into a 1" microphone's dimensions (with grid). Allows mounting of 1" microphone protection grid. Typically used with 45CA Hearing-protector Test Fixture.

GRAS RA0070

Test Base for Ear Simulators



Test base for GRAS ear simulators and couplers.

GRAS RA0076

Adapter for NBS 9-A Coupler RA0075



RA0076 is a thread adapter exclusively for use in connection with RA0052 Test Jig. It can also be used when upgrading the 43XX Series Ear Simulator Kits, except 43AF, where it is included.