

## COMPOSER Georg C. Wagenseil- SEIBOLD Online-Analyser for Manganese

### Sources

**Natural sources.** Manganese is one of the most abundant metals in the Earth's crust, usually occurring with iron.

**Industry.** Manganese is used principally in the manufacture of iron and steel alloys, as an oxidant for cleaning, bleaching and disinfection as potassium permanganate and as an ingredient in various products. More recently, it has been used in an organic compound, MMT.

**Drinking water.** Manganese is naturally occurring in many surface water and groundwater sources, particularly in anaerobic or low oxidation conditions. A provisional health-based guideline value of 0.5 mg/litre should be adequate to protect public health.

**Toxicity.** Manganese is an essential element for humans and other animals. Adverse effects can result from both deficiency and overexposure. Manganese is known to cause neurological effects following inhalation exposure

### Method

Metal is measured as chelate complex between metal ions in the waste water and sensitive spectrophotometric reagent dye. Change of the intensity of the visible light throughout cuvette containing formed metal complex is directly proportional to metal concentration.



### Advantage of the system

- Non toxic chemistry !!!
- Robust design.
- Minimal maintenance.
- Easy handling.
- High accuracy and precision.
- Suitable for mission critical applications.
- Automated cleaning and calibration.

| System information       |  |
|--------------------------|--|
| Measurement variable     | Manganese (Mn)   |
| Measurement application  | Drinking water, river monitoring, electroplating and semiconducting industry |
| Measurement ranges       | 0.005 – 1.00 mg/L (ppm)<br>other ranges possible upon request                |
| Accuracy and Precision   | ± 3 % (based on full scale)  |
| Resolution               | 0.005 mg/L   |
| Calibration and cleaning | automated  |
| Seibold Reagent kit      | Buffer and Dye<br>Provided by Sigma Aldrich                                  |

(ES) Equipements Scientifiques SA - Département Bio-Tests & Industries - 127 rue de Buzenval BP 26 - 92380 Garches Tél. 01 47 95 99 90 - Fax. 01 47 01 16 22 - e-mail: bio@es-france.com - Site Web: www.es-france.com



# Continuous Analysis. Reliable Results.

## COMPOSER Georg C. Wagenseil- SEIBOLD Online-Analyser for Manganese

#### **MEASUREMENT INFORMATION**

#### **Measurement method**

Spectrophotometric (LED, detector)

**Measurement interval** 

Continuous; Discontinuous (programmable, external start)

Sample and Reagents consumption per measurement

Sample: ~ 75 - 200 ml

Seibold Buffer and Reagent: ~ 3 ml

**ENVIRONMENTAL DATA** 

Ambient operating temperature, sample temperature: 5 to 40°C

Ambient operating humidity: Up to 95 % RH non-condensing (bellow the condensation limit)

**ELECTRICAL DATA** 

**Power supply** 

Supply voltage: 220 ... 230 V AC, 50...60 Hz (110 V AC or 24 V DC, optional)

Power consumption: approx 50 VA

Output signal: 4...20 mA

Screen

Color, TFT, liquid crystal display (LCD) with built-in backlight and brightness adjustment.

MAINTENANCE

Maintenance interval: 3 months

